


# CONVENTIONAL REEL

# SALTIST35P/40P/50P

\*Please order by parts number, not key number.



Key	Part No	Description
1	E75-3001	FRAME ASSY
2	E72-5101	CLICK LEVER
3	E72-5201	CLICK LEVER COLLAR
4	E72-5301	CLICK LEVER WASHER
5	E61-7403	CLIC PLATE WASHER (A)
6	E61-7401	CLIC PLATE WASHER (B)
7	E67-9301	CLIC PLATE
8	373-1604	CLIC PLATE WASHER (C)
9	320-1402	CLIC PLATE RETAINER
10	E74-4801	CLICK PLATE SPRING
11	375-7404	LS BEARING WASHER (A)
12	E71-0501	LS BEARING WASHER (B)
13	E70-3301	LS BEARING WASHER (C)
14	G42-7702	LS BALL BEARING
15	E70-9501	LS BEARING RING
16	E71-6911	RS COVER PLATE
17	E70-9701	RS COVER PLATE SCREW
18	E75-3101	SPOOL ASSY
19	E72-4401	CLICK GEAR
20	375-8501	CLICK GEAR WASHER
21	320-7601	CLICK GEAR RETAINER
22	E74-4301	BREKE COLLAR (A)
23	E75-1001	SET PLATE
24	E70-0701	SET PLATE BEARING COLLAR
25	G15-6803	SET PLATE BALL BEARING
26	E75-1801	SET PLATE BEARING RING
27	E71-7902	SLIDE PLATE
28	E70-9801	SLIDE PLATE SCREW WASHER
29	E70-6801	SLIDE PLATE SCREW
30	E75-4401	GEAR SHAFT
31	E57-5301	GEAR SHAFT BALL BEARING
32	E70-0601	GEAR SHAFT PLATE
33	320-8002	GEAR SHAFT BEARING RETAINER
34	E70-9901	GEAR SHAFT WASHER
35	E75-1701	GEAR SHAFT PLATE SCREW
36	E70-1101	CLUTCH PLATE
37	E71-8301	CLUTCH PLATE SPRING
38	E71-8401	STOPPER PIN
39	E68-3501	STOPPER ASSY
40	E71-8602	RATCHET
41	E71-8801	DRIVE GEAR WASHER
42-D	E75-7501	DRIVE GEAR
42-P	E74-2301	PINION GEAR
43	E72-2001	DRAG WASHER
44	E72-1901	DRAG DISC WASHER
46	E72-2101	DRAG LIP WASHER
47	E75-3601	DRAG DISC WASHER (B)
48	E72-5601	DRAG DISC WASHER O-RING
49	E70-6501	SIDE PLATE PIN
50	E75-1104	RS PLATE
51	E63-3301	ONEWAY CLUTCH
52	E74-9701	CLUTCH LEVER (A)
53	E70-6901	CLUTCH LEVER WASHER (A)

Key No	Part No	Description
54	E71-1101	CLUTCH LEVER WASHER (B)
55	E70-0101	CLUTCH CAM PLATE
56	E70-7501	CLUTCH CAM
57	320-7601	CLUTCH CAM RETAINER
58	E70-6401	CLUTCH CAM SPRING
59	E75-3901	PINION BEARING
60	E72-0101	PINION BEARING RING
61	E72-0201	MECHANICAL BRAKE O-RING
62	E75-4001	MECHANICAL BRAKE KNOB
63	B17-5503	MECHANICAL BRAKE WASHER (A)
64	E72-5001	MECHANICAL BRAKE WASHER (B)
65-1	E72-0701	RS PLATE SCREW (A)
65-2	E72-0702	RS PLATE SCREW (B)
66	E68-8801	RS PLATE SCREW O-RING
67	E75-4101	RS PLATE SCREW (C)
68	E72-0901	SET PLATE SCREW
69	E61-0701	CLUTCH RING
70	E70-9105	GEAR SHAFT WASHER
71	E72-9601	GEAR SHAFT O-RING
72	G52-3403	HANDLE BALL BEARING
73	E70-9103	HANDLE BEARING WASHER
74	E70-9201	DRAG HOLDER
75	E71-5601	DRAG HOLDER LEAF SPRING
76	E72-1001	DRAG SPRING WASHER
77	G69-4201	STAR DRAG WASHER
78	E72-1501	DRAG NUT
79	E71-1701	DRAG NUT SPRING
80	E72-1104	STAR DRAG
81	E71-5101	HANDLE WASHER (A)
82	E71-1901	HANDLE WASHER (B)
83	E75-4201	HANDLE ASSY
84	G22-0306	HANDLE NUT
85	G21-8201	HANDLE NUT SCREW
86	E77-4101	CLAMP BOLT
87	E62-4402	ROD CRAMP
88	H60-0801	CLAMP NUT
89	B35-2701	BREKE COLLAR (B)
90	E61-4001	CLAMP NUT (B)

### SALTIST40P Special Parts

Key	Part No	Description
1	E75-4501	FRAME ASSY
16	E71-6912	RS COVER PLATE
18	E75-4601	SPOOL ASSY
50	E75-1105	RS PLATE

### SALTIST50P Special Parts

Key	Part No	Description
1	E75-5101	FRAME ASSY
16	E71-6913	RS COVER PLATE
18	E75-5201	SPOOL ASSY
50	E75-1106	RS PLATE

Key No	Part No	Description
91	6E7543010	HANDLE ARM
92	375-3004	WASHER
93	F64-8301	BUSHING
94	6E7570010	HANDLE KNOB
95	E45-4001	SCREW A
96	6E6401020	COLLAR
97	H10-0001	O RING
98	6E6471041	SCREW