


BAITCASTING REEL

STZCTSV700H/XH

*Please order by parts number, not key number.



Key No	Part No	Description
1	J74-1101	LS PLATE
2	J63-1901	LEVER PLATE SPRING
3	J28-6301	LEVER PLATE PIN
4	J74-1601	LEVER PLATE (A)
5	J74-2601	LEVER PLATE (B)
6	J74-1703	LEVER PLATE (C)
7	G94-0402	BRAKE DIAL SCREW
8	H15-9201	BRAKE DIAL WASHER
9	J74-1801	BRAKE DIAL
10	H66-3401	BRAKE DIAL LEAF SPRING
11	J74-1301	SET PLATE
12	J74-1901	MAGNET HOLDER
13	H66-6002	SET PLATE SCREW
14	J74-2201	MAGNET HOLDER RING
15	375-7404	LS BEARING WASHER(A)
16	375-7411	LS BEARING WASHER(B)
17	G18-5101	LS BEARING WASHER(C)
18	G51-1506	LS BALL BEARING
19	F03-2201	LS BALL BEARING RING
20	320-8002	SPOOL HOLDER SPRING RETAINER
21	J49-7001	SPOOL HOLDER SPRING WASHER
22	H86-2301	SPOOL HOLDER SPRING
23	J91-4001	SPOOL HOLDER
24	J19-0301	SPOOL HOLDER COLLAR
25	E09-6501	SPOOL HOLDER WASHER
26	Z02-4547	SPOOL UNT (20-28)
27	J25-2301	SPOOL PIN
29	J73-8203	FRAME
30	J74-0904	FRONT COVER
31	H53-1507	FRONT COVER SCREW
32	J73-9201	CLUTCH LEVER
33	J73-8401	CLUTCH LEVER PLATE(R)
34	J73-8501	CLUTCH LEVER PLATE(L)
35	J74-1001	OSCILLATING POST
36	H70-4101	OSCILLATING POST RETAINER
37	J73-8601	RS COVER PLATE
39	G43-1002	CLUTCH CAM BALL BEARING
40	J76-4501	CLUTCH BALL BEARING COLLAR
41	J73-9101	KICK LEVER PLATE (A)
43	J91-5201	KICK LEVER PLATE SPRING
44	J62-2901	KICK LEVER
45	J73-9001	CLUTCH CAM PLATE
46	H92-8801	CLUTCH CAM PLATE SPRING
47	J05-5201	CLUTCH CAM PLATE PIN
48	J73-8701	CLUTCH CAM
49	H45-0701	CLUTCH CAM PLATE WASHER(A)
50	B36-0405	CLUTCH CAM PLATE SCREW
51	H65-9103	KICK LEVER PLATE(B)
52	G91-3306	KICK LEVER PLATE(B) WASHER
53	B03-2905	KICK LEVER PLATE(B) SCREW
54	H92-9001	CLUTCH PLATE
55	J31-3901	CLUTCH SPRING
56	Z02-4637	PINION GEAR + DRIVE GEAR UNIT
57	H44-8402	PINION RING
58	G53-8003	PINION BALL BEARING
59	J72-4601	PINION BALL BEARING COLLAR
60	J28-5901	CLUTCH SPRING PLATE
61	J76-3501	RS PLATE
62	J27-9701	MECHANICAL BRAKE O RING

Key No	Part No	Description
63	G93-1001	PINION SHAFT
64	H16-1001	MECHANICAL BRAKE WASHER(A)
65	B17-5503	MECHANICAL BRAKE WASHER(B)
66	J27-9601	MECHANICAL BRAKE KNOB
67	G94-5806	RS PLATE SCREW(A)
68	320-5901	WORM SHAFT RETAINER
69	B41-1702	WORM SHAFT WASHER
70	G46-9001	WORM SHAFT BALL BEARING
71	J73-9504	LEVEL WIND
72	J74-0101	PAWL
73	G09-9801	PAWL WASHER
74	J74-0201	LEVEL WIND PIN
75	G25-2202	LEVEL WIND O RING
76	J28-1601	WORM SHIELD PLATE
77	J74-0001	WORM SHIELD
78	J73-9901	WORM SHAFT
80	J28-1401	WORM SHAFTGEAR
81	B33-9801	WORM SHAFT GEAR RETAINER
84	G46-6205	GEAR SHAFT BALL BEARING
85	J28-1201	GEAR SHAFT PLATE(A)
86	J28-1101	GEAR SHAFT PLATE(B)
87	G29-7006	GEAR SHAFT PLATE SCREW
88	J28-1001	WORM GEAR
89	J73-9401	GEAR SHAFT
90	H66-0901	RATCHET
91	374-6605	DRIVE GEAR WASHER
93	H35-9001	DRAG WASHER
94	J74-0501	DRIVE COLLAR
95	J41-0801	DRIVE COLLAR SPRING
96	J56-6201	DRIVE COLLAR PIN
97	G01-1401	DRAG COLLAR
98	J54-0401	ONEWAY CLUTCH
100	B55-3801	HANDLE BALL BEARING WASHER
101	F02-8203	DRAG HOLDER
102	F03-2401	DRAG HOLDER LEAF SPRING
103	150-8901	DRAG SPRING WASHER
104	H92-9501	STAR DRAG WASHER
105	J14-1001	DRAG NUT
106	J01-1901	DRAG NUT SPRING
107	J29-5403	STAR DRAG
108	F57-6601	HANDLE WAHSER
109	J74-0601	HANDLE ASSEMBLY
110	J29-5501	HANDLE SCREW
111	J31-9201	HANDLE LOCK PLATE
112	G83-5502	HANDLE LOCK PLATE SCREW
200	H74-4801	HANDLE KNOB SP WASHER
201	B41-1703	HANDLE KNOB WASHER
202	G46-9007	HANDLE KNOB BALL BEARING
203	J31-5504	HANDLE KNOB
204	G72-0001	HANDLE KNOB BALL BEARING
205	B67-9308	HANDLE KNOB SCREW
206	J31-5801	HANDLE KNOB CAP
207	J37-4301	FRAME COVER SHEET

STZCTSV700XH Special Parts

Key No	Part No	Description
56	Z02-4544	PINION GEAR + DRIVE GEAR UNIT
61	J73-7801	RS PLATE
111	J31-9204	HANDLE LOCK PLATE