


BAITCASTING REEL

TAELPF103HSL/XSL

*Please order by parts number, not key number.



Key No	Part No	Description
1	J71-6301	BRAKE DIAL SCREW
2	E16-7101	BRAKE DIAL SPRING
3	J69-4902	BRAKE DIAL
4	B33-9801	BRAKE DIAL RETAINER(A)
5	F63-7701	BRAKE DIAL COLLAR
6	J88-6201	BRAKE DIAL LEAF SPRING
7	J91-0101	RIGHT SIDE PLATE
8	J84-3301	BRAKE DIAL RETAINER(B)
9	G93-9301	BRAKE DIAL RETAINER(B) SCRERW
10	J69-5001	MAGNET HOLDER
11	375-7404	RS BEARING WASHER (A)
12	375-7411	RS BEARING WASHER (B)
13	G18-5101	RS BEARING WASHER (C)
14	G51-1503	RS BALL BEARING
15	F03-2201	RS BEARING RING
16-24	Z02-5179	SPOOL ASSY (16-24)
25	J71-5305	FRAME
26	J69-4605	FRONT COVER
27	H53-1508	FRONT COVER SCREW
28	J69-3301	CLUTCH LEVER
29	J69-2801	CLUTCH LEVER PLATE (R)
30	J69-2701	CLUTCH LEVER PLATE (L)
31	J28-1902	OSCILLATING POST
32	H70-4101	OSCILLATING POST RETAINER
33	J69-3401	CLUTCH CAM PLATE PIN SPRING COLLAR
34	H92-8801	CLUTCH CAM PLATE PIN SPRING
35	J05-5201	CLUTCH CAM PLATE PIN
36	B86-1704	CLUTCH CAM BALL BEARING
37	J71-5701	KICK LEVER PLATE (A)
39	J40-7801	KICK LEVER SPRING
40	J63-8601	KICK LEVER
41	J71-5401	CLUTCH CAM PLATE
42	H15-9202	CLUTCH CAM PLATE SCREW WASHER
43	352-2501	CLUTCH CAM PLATE SCREW
44	H65-9101	KICK LEVER PLATE (B)
45	B03-2904	KICK LEVER PLATE (B) SCREW
46	H94-4401	CLUTCH PLATE
47	J31-3901	CLUTCH SPRING
48	J71-6402	PINION GEAR
49	E21-9701	PINION RING
50	G43-1102	PINION BALL BEARING
51	J87-7305	LEFT SIDE PLATE
52	B05-5201	ZERO ADJUSTE O-RING
53	J21-3101	ZERO ADJUSTE WASHER (A)
54	B17-5501	ZERO ADJUSTE WASHER (B)
55	J90-9701	ZERO ADJUSTE KNOB
56	G04-0830	LS PLATE SCREW (A)

Key No	Part No	Description
57	320-5901	WORM SHAFT RETAINER(A)
58	B41-1702	WORM SHAFT WASHER(0.1MM)
59	G72-0001	WORM SHAFT COLLAR
60	J24-3303	LEVEL WIND
61	121-4212	PAWL
62	373-1303	PAWL WASHER
63	F40-2801	PAWL HOLDER NUT
64	J71-5801	WORM SHIELD
65	J24-3601	WORM SHAFT
67	J69-3901	WORM SHAFT GEAR
69	G09-9801	GEAR SHAFT WASHER(0.1MM)
70	320-8002	GEAR SHAFT RETAINER
71	G46-6202	GEAR SHAFT BALL BEARING
72	J69-3701	GEAR SHAFT PLATE
73	E13-4509	GEAR SHAFT PLATE SCREW
74	J69-3601	WORM GEAR
75	J90-9802	GEAR SHAFT
76	H66-0901	RATCHET
77	H66-1101	DRIVE GEAR WASHER(A)
78	H35-9001	DRIVE GEAR WASHER(B)
79	J71-6502	DRIVE GEAR
80	H35-9002	DRAG WASHER
81	J69-4401	DRAG DISC WASHER
82	J90-9901	DRAG COLLAR
83	G81-9801	ONEWAY CLUTCH
85	B55-3801	HANDLE BALL BEARING WASHER
86	F02-8203	DRAG HOLDER
87	F03-2401	DRAG HOLDER LEAF SPRING
88	150-8901	DRAG SPRING WASHER
89	H92-9501	STAR DRAG WASHER
90	J10-2304	DRAG NUT
91	J01-1901	DRAG NUT SPRING
92	J14-0005	STAR DRAG
93	F57-6601	HANDLE WAHSER
94	J92-6701	HANDLE ASSY
95	G79-3310	HANDLE NUT
96	J62-5401	HANDLE LOCK PLATE
97	J63-2302	HANDLE LOCK PLATE SCREW

TAELPF103XSL Special Parts

Key No	Part No	Description
48	J81-7601	PINION GEAR
51	J87-7306	LEFT SIDE PLATE
62	373-1300	PAWL WASHER
69	G09-9800	GEAR SHAFT WASHER(0.1MM)
79	J81-7701	DRIVE GEAR