General Operation

Power On and Off

- Mains power lead and switch is at bottom rear of machine
- Plug in the supplied lead and turn on the power switch (I ON & O OFF)
- Press power button on right side of machine
- Wait 30 seconds to power up and jukebox will automatically play
- To turn off simply press power button on right side of machine.

Adding songs to queue

- Enter ALBUM NUMBER
- Enter SONG NUMBER
- Press PLAY
- Press BACK if error has been made
- NOTE: Enter '00' as SONG NUMBER to add entire ALBUM to queue

Additional Information

- Press LEFT & RIGHT to browse albums
- NEXT to skip songs in queue
- RANDOM songs will be played if no songs in queue



Adding Songs

Adding songs to your jukebox requires that you have your songs on a computer in mp3, or wav format.

Please ensure the jukebox is powered 'off' before starting the procedure.

- Open the front door of the jukebox with the key located on the right hand side of the door panel. Insert and turn the key, then pull entire door open.
- In the middle rack unplug the USB stick labeled MUSIC. Note: Take note of which USB port it was plugged in to.
- Insert USB stick in to your computer.
- Using a file browser, open the MUSIC folder on the USB stick.
- Create a FOLDER in your USB stick for the name of the artist. Eg ABBA
- Inside that ARTIST FOLDER create another FOLDER with the name of the album. Eg. Greatest Hits
- Have your MP3 files ready with file names matching the song name. eg. Dancing Queen.mp3
- Copy all of the files for that album into the new album folder you have created.

Your directory structure should be...

USB STICK DRIVE\MUSIC\Artist Name\Album Name\Song Name.mp3

- To include an image of the album cover please save a 'jpg' file to the same folder. The 'jpg' must be named '**Folder.jpg**'
- Once finished plug the usb stick back into the same USB position inside the jukebox.
- Power on your jukebox and the new album will be automatically allocated a new album number.