


PLEASE READ ALL INSTRUCTIONS BEFORE SETUP OR FOLDAWAY OF YOUR STRUCTURE.

© 2019 Bresser
1010 S 48th Street, Springdale, AR 72762
explorescientificusa.com | bresserusa.com | 866.252.3811
All rights reserved. Made in China.

⚠ WARNING:
KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC. This tent meets the flammability requirements of CPAI-84. The fabric may burn if left in continuous contact with any flame source.

CAUTION:
This structure may use a spring steel loop that will pop open quickly! Caution must be used in the handling of this product. Small children should never be allowed to fold or unfold this product without adult supervision. Discard if steel loop is broken or if this product is damaged. It is fire resistant only. The fabric will burn if it is left in continuous contact with flame and heat sources. Keep all flame and heat sources away from this product. Please thoroughly read instruction sheet before using this product.



SETUP



Bottom Base




Slide Pole Through (3) Pockets



Place Pole Through (1) Pocket of the Top Base



Click Retaining Clip & Tie a Slip Knot on the Hook To Secure



Top Cover



Place Poles Into Opposite Corner Pockets



Tie Knot Around Poles To Secure



Place Top Cover & Pull Down

