




Instructions Manual Ver 1.00

ST-050
Jikaro Firering Table

Thank you for purchasing this Snow Peak product. This product is a table that surrounds the Pack & Carry Fireplace (L)/(M) (ST-032R/ST-033R) and the GigaPower LI Stove (GS-1000). In order to ensure your safety when using this product, please read these instructions carefully before use. Please be sure to keep this document for future reference. Although this product is expected to be complete and safe, please check all accessory items and practice assembling and handling it in a safe location prior to use in the field. If there is an item in the instructions that you do not understand, or if you find a fault in the product, stop use immediately and consult where the store you purchased this product or contact our User Service department.

Contents of Set (Names of Parts)



Specifications

- Materials: Tabletop: Stainless steel, Legs: Stainless steel, Knobs: Aluminum alloy
- Size: When using Pack & Carry Fireplace (L): 1,120×1,120×400mm (opening 600×600mm)
When using GigaPower LI Stove: 890×890×400mm (opening 370×370mm)
- Storage size: 745×170×400mm
- Weight: 10.5kg

Before use: Please read thoroughly to use safely and avoid expected accidents.

- ⚠ DANGER: Indicates actions from which life-threatening, major accidents are clearly expected.
- ⚠ WARNING: Indicates actions which, depending on the circumstances, may lead to major accidents.
- ⚠ CAUTION: Indicates actions which may lead to injury, damage to this product, or damage to other items.


Precautions for Use

- ⚠ DANGER: Indicates actions from which life-threatening, major accidents are clearly expected.


- Read the instruction manuals for each item you are using in combination with this product.

⚠ WARNING: Indicates actions which, depending on the circumstances, may lead to major accidents.

- Do not use gas-powered devices (lanterns, stoves) on the tabletop.
- Do not place combustible objects or objects that are easily affected by heat on the tabletop.
- Do not use this product on sloping or unstable ground, as this could lead to it tipping over, which could cause serious accidents.
- When using any devices that involve fire, do not use under or near anything that combusts easily (tent, tarp, dry grass, etc.).
- If you are moving this product, changing its assembly pattern, or changing any other items, extinguish any flames in the Fireplace or Stove and ensure that all items have sufficiently cooled first. Failure to do so may result in burns.
- If using the Pack & Carry Fireplace (L)/(M) (ST-032R/ST-033R), do not perform any actions to purposefully create pillars of fire. Do not make an open fire using logs when there are strong winds, etc. Flames could rise up, causing burns or fire.




- Depending on the items used, in addition to strong sunlight, this product and its surrounding area may become extremely hot. Take care not to get burned.
- The maximum load of this product is 20kg per tabletop section. Do not place anything exceeding that weight on top.
- Do not allow infants or small children to lie or sit on the table.
- Do not sit or lean on the tabletop.
- Pay close attention to the fire and surrounding environment during use. Especially keep a constant watch over small children while fire is being used.
- Read the “Method of Use” section thoroughly, and only use this product after confirming that it is set up correctly. The product could tip over or cause a fire or burns if not set up correctly.
- Place the source of fire being used directly in the center of the product’s opening.



Wood and gas-powered devices (GigaPower LI Stove, etc.) cannot be used in combination with this product if a table is connected to it.

⚠ CAUTION: Indicates actions which may lead to injury, damage to this product, or damage to other items.


- Do not place any objects that are easily affected by heat near the opening.
- This product is not meant for permanent use.
- Although the main unit is made of stainless steel, certain conditions may cause it to rust.
- Ensure that the threading of the connecting wheels does not get sand or dirt in it.




The area near the opening and objects placed near the opening can become heated due to far-infrared rays from the heat source. Do not place any objects that are easily affected by heat near the opening, and be cautious of burns.

Method of Use


■ Assembling the tabletop and legs



(1) Turn the tabletop section upside down, and insert the A side of the leg into groove A (2 locations).




(2) Extend the B side of the leg until it reaches groove B (2 locations), and firmly insert as shown in the diagram above. Take care not to overextend the leg, as this could deform it. If a leg has become deformed, refer to the Maintenance section of this document and adjust the leg.



(3) Confirm that the leg is inserted into all 4 grooves, and turn it right side up by holding both the tabletop and leg.

■ Assembly pattern 1 (combined with the Pack & Carry Fireplace (L)/(M) (ST-032R/ST-033R))

Line up the 4 assembled tabletop and leg components as shown in the diagram below, and connect the tabletop sections together.




How to connect the tabletop sections together

(1) Loosen the connecting wheels A until about 5 to 10mm of each screw is visible. Slide the notches A into the knob portions of the connecting wheels.

- (2) Adjust the positioning so that the connecting knobs are engaged with the indents on the sides of the tabletop sections.
- (3) Turn the knobs on the connecting wheels A by running your finger along them from the notches A, bringing the tabletop sections together. Be careful not to overtighten.

■ Install the Pack & Carry Fireplace (L)/(M) (ST-032R/ST-033R)

Install the Pack & Carry Fireplace (L)/(M) (ST-032R/ST-033R), Fireplace Base Plate (L)/(M) (ST-032BP, ST-033BP), and Base Plate Stand (L/M) (ST-032BS) in the center of the opening, as shown in the diagram below.




⚠CAUTION

- The Fireplace Base Plate and Base Plate Stand (L/M) must be used.
- Thoroughly read the instruction manual for each item before use.

■ Assembly pattern 2 (combined with the GigaPower LI Stove (GS-1000))

Line up the 4 assembled tabletop and leg components as shown in the diagram below, and connect the tabletop sections together.




How to connect the tabletop sections together

- (1) Loosen the connecting wheels B until about 5 to 10mm of each screw is visible. Slide the notches B into the knob portions of the connecting wheels.
- (2) Adjust the positioning so that the connecting knobs are engaged with the indents on the side of the tabletop sections.
- (3) Turn the knobs on the connecting wheels B by running your finger along them from the notches B, bringing the tabletop sections together. Be careful not to overtighten.

■ Install the GigaPower LI Stove (GS-1000)


Set the GigaPower LI Stove (GS-1000) to a total height of 38 to 42cm, and install it in the center of the opening, as shown in the diagram below.



⚠CAUTION


- Thoroughly read the instruction manual for the GigaPower LI Stove (GS-1000) before use.
- The Pack & Carry Fireplace (L)/(M) (ST-032R/ST-033R) cannot be used with this combination pattern.

■ Connection with a Bamboo Table Regular or Bamboo Table Long (CK-116T, CK-117T)





The Jikaro Table can be connected to a Bamboo Table Regular or Bamboo Table Long (CK-116T, CK-117T) using the multifunctional connecting holes. Use the 400 Leg Set (CK-112) for the Bamboo Table Regular or Bamboo Table Long.

Insert the hooks on one end of the Bamboo Table into the multifunctional connecting holes, as shown in the diagram to the left. Read the instruction manual for each item before use.




■ Storage

Place the four tabletop sections between the legs, which have been stacked together as shown in the diagram below. Place everything into the storage case.



Maintenance

- Using a hard scrubbing brush, etc. to clean this product will scratch it.
- Store out of direct sunlight in a well-ventilated area with little humidity.
- If light grime or water gets on this product, promptly wipe with a dry cloth and allow it to dry sufficiently.
- If salt (seasoning, etc.) or other chemicals get on this product, wipe thoroughly with a well-wrung cloth and allow it to dry sufficiently.
- If you overextend a leg past the point at which the A side and B side of the leg align with groove A and groove B, place the leg on a flat surface and correct it by placing even pressure onto it, as shown in the diagram to the right.



Quality Assurance

This product is expected to be complete and safe. However, in the unlikely event that any product you have purchased is defective, contact the store where you purchased it or our User Service department. If it is a manufacturing defect, the product will be repaired or replaced free of charge. In any other cases, the product will be repaired for a reasonable price. Whether a product will be repaired or replaced will be determined at our discretion.

The product may not be guaranteed or repaired in the following cases.

1. The product was not used according to the instruction manual.
2. The product's life span has been reached due to the aging of its materials.
3. The product was damaged by modification or rough handling.
4. The product was damaged by an unforeseen accident.
5. The product was damaged by something other than a manufacturing defect.
6. The product was damaged by dirt or rust.
7. A malfunction or breakage occurred due to disassembly.
8. A malfunction occurred due to part deformation or breakage caused by dropping or other impact.
9. The deterioration, breakage, or damage of a consumable part, or associated malfunction.
10. The product was damaged due to it being used in combination with another company's product.

Repairs

- If serious repairs are required, please contact the store where you purchased this product or contact our User Service department.
- If you are asked to send the product for repairs, ensure that it is sufficiently dry and clean before sending it.
- Attach a memo or ticket to the product so that our team can clearly understand what needs to be repaired. Include as many details about the state of the damage as possible.
- Freight and repair expenses will be handled as follows.
 1. If covered by warranty: Our company will bear the round trip freight expenses and repair expenses.
 2. If not covered by warranty: The customer will bear the round trip freight expenses and repair expenses.

If you have any questions or concerns, please consult the store where you purchased this product or contact our User Service department.

Snow Peak User Service

0120-010-660 (9:00am – 5:00pm)
userservice@snowpeak.co.jp

Snow Peak Inc.

456 Nakanohara, Sanjo-shi,
Niigata-ken 955-0147
TEL: 0256-46-5858
FAX: 0256-46-5860
www.snowpeak.co.jp

MADE IN KOREA