

**ROKINON** CINE DSX



**50mm T1.5  
CINE DSX  
Instruction Manual**

Thank you for purchasing the ROKINON Cine DSX 50mm T1.5 Full Frame prime lens.

Please read this instruction manual prior to use to familiarize yourself with functions of the lens, the operating method, and cautions.

**FEATURES**


- Available in mounts to fit all major camera brands, and offering Full Frame coverage, it will provide high quality video and still images with Mirrorless and DSLR cameras of any sensor size.
- The fast T1.5 aperture supports shooting even in low-light situations, and can provide a shallow depth of field for precise selective focus control to highlight your subject.

- It offers full cine lens features including a de-clicked aperture control, industry standard 0.8 MOD focus and aperture ring gearing, a precise and smooth long focus throw, T-stop calibration, and tight color matching.
- Additional features include a nine blade aperture for smoother bokeh, weather sealed mounts (Except Nikon), and the distance scales, aperture settings, and focal length markings are visible from both sides of the lens.
- The nine elements in six groups design utilizes two specialized elements including one Aspherical and one Hybrid Aspherical types, plus UMC anti-reflective coatings for clear and vibrant images.
- Its compact size and light weight design with gears that are designed to be smoother to the touch, enhance comfort and stability for hand-held and gimbal shooting.

**Cautions**

- Do not look directly at the sun through the lens as it may seriously impair your vision.
- Attach or detach the lens only while the camera is turned off.
- Protect the lens from water, high humidity and excessive heat.
- Avoid subjecting the lens to drastic temperature changes such as moving from a very cold outdoors location to a warm indoors location. This can cause moisture in the air to condense inside or on the outside of the lens and lead to failure or mold production.
- Before taking the lens indoors from a cold outdoors location, put the lens in a plastic bag or sealed camera bag, and remove it only when the lens has warmed up to room temperature.

**Parts**



- |                             |                               |
|-----------------------------|-------------------------------|
| 1) MOUNT                    | 6) HOOD                       |
| 2) DISTANCE SCALE INDEX     | 7) DEPTH OF FIELD SCALE       |
| 3) LEFT SIDE DISTANCE SCALE | 8) APERTURE INDEX             |
| 4) FOCUSING RING            | 9) APERTURE RING              |
| 5) HOOD MOUNT               | 10) RIGHT SIDE DISTANCE SCALE |

**Attaching the Lens**

- Align the index mark on the lens barrel with the index mark on the lens mount of the camera.
- Do not press the lens release button on the camera when mounting the lens.
- Insert the lens into the camera mount and rotate it clockwise (Counterclockwise for Nikon mounts) until it "clicks" and locks into place. Do not insert the lens at an angle.
- Remove the front lens cap when you are ready to shoot.
- Attach the front lens cap.
- While holding down the lens release button on the camera body, rotate the lens counterclockwise (Clockwise for Nikon mounts) until it stops and separate the lens from the body.
- Attach the rear lens cap.

**Aperture Adjustment and Exposure Modes**

If your camera will not record video or shoot in still mode, make sure you are in either Manual or Aperture Priority exposure control mode, and that "release without lens" is enabled within your camera's menus.

- Aperture adjustment is done directly on the aperture ring of the lens, NOT from a control on your camera.
- It is suggested that ISO be set manually, NOT on auto. Set it to a sensitivity appropriate for the subject, lighting conditions, and speed/aperture settings you want to utilize

**Focusing**

Check your camera's instruction book for manual focusing methods including Focus Peaking and Focus Magnification. Please note that available focusing methods may vary depending on your camera model.

- Set the Focus Mode of your camera to Manual Focus.
- Set the lens to its maximum aperture of T1.5. This enables you to critically focus by eliminating the influence that depth of field provides at smaller apertures.
- After achieving critical focus at T1.5, set your shooting aperture.
- Precise Infinity Focus NOT located at the focus stop at the infinity end of the focus scale. The exact point on the focusing scale for critical infinity focus will vary depending on camera and lens mount, wear, temperature, and normal design tolerances.

**Cleaning**

- It is extremely important before cleaning to dust off the lens surface using a lens blower or a soft brush to remove any foreign particles or grit that could scratch the lens.
  - For stubborn spots, use only one or two small drops of a reputable lens cleaner on a microfiber cloth, and gently wipe the lens in a circular motion.
- DO NOT USE AN ORGANIC SOLVENT SUCH AS PAINT THINNER, ALCOHOL, OR BENZENE.**

## Product Specifications

Model	ROKINON CINE DSX 50mm T1.5					
Aperture Range	T1.5 – 22					
Mount	CANON EF	CANON RF	NIKON	SONY E	FUJIFILM X	CANON M / MFT
Angle of View (Full Frame / APS-C)	46.2° / 29.4°	46.2° / 29.4°	46.2° / 31.3°	46.2° / 31.3°	31.3°	29.4° / 23.0°
Length	2.94" (74.7mm)	3.19" (81.1mm)	2.84" (72.1mm)	3.96" (100.6mm)	3.98" (101.3mm)	3.92" (99.5mm)
Weight	18.57oz (525.8g)	20.83oz (590.6g)	18.16oz (514.8g)	20.33oz (576.4g)	20.01oz (567.6g)	20.08oz (569.4g) / 19.89oz (563.8g)
Optical Construction	9 Elements in 6 Groups (1 ASP, 1 Hybrid ASP, with UMC Coating)					
Minimum Focusing Distance	17.7" (0.45m)					
Filter Size	77mm					
Number of Aperture Blades	9					
Maximum Diameter	3.31" (84mm)					
Focus Throw / Aperture Throw	150° / 48°					

-The minimum focus is the distance from the image sensor to the object.  
 -The product specifications and exterior are subject to change without notice.  
 -The supported functions of this product may vary according to the camera brand and model.

### Included Components

- Instruction Manual / Warranty
- Front Lens Cap
- Soft Lens Pouch
- Rear Lens Cap

### Contacts

Elite Brands Inc.  
 ROKINON Division  
 New York, NY 10005

Toll Free: 800.441.1100  
 Phone: 212.947.7100  
 support@rokinon.com

rokinon.com  
 facebook.com/rokinonlenses  
 instagram.com/rokinon

ROKINON® is a registered trademark of Elite Brands Inc.  
 ©2020, Elite Brands Inc., New York, NY 10005



**IMPORTANT!**  
**BEFORE ORDERING YOUR ROKINON LENS OR ACCESSORY PLEASE CALL 1-800-441-1100 (TOLL FREE) OR VISIT**  
**OUR TECHNICAL SUPPORT TO OBTAIN A WARRANTY AFTER-PURCHASE!**

1. The product or the part is determined to be defective a warranty authorization number will be provided.  
 2. Please follow the steps of the instruction with all accessories, lenses and related parts of accessories.  
 3. From the payment card with sufficient authorization information and only a payment card number for all orders to:  
**ELITE BRANDS INC., Attn: Service Dept., 40 West Street, 10th Floor, New York, NY 10005.**

**ROKINON U.S.A. LIMITED TWO YEAR WARRANTY**

Your ROKINON product or the model and serial number or the rights warranted by Elite Brands Inc. against defective workmanship or materials for two (2) years from the date of purchase.

Elite Brands Inc. will not be liable, either express or implied, for consequential damages, including lost profits, for any reason, in connection with the use of any ROKINON product. The product has been designed to be used in accordance with the instructions provided in the user manual.

This warranty does not apply to equipment or accessories not manufactured or repaired by Elite Brands Inc. or if the equipment is not of warranty, or has been changed, tampered with, accident, abuse, misuse, fire, flood, lightning, or other causes, or if the equipment is not used in accordance with the instructions, or if the equipment has been modified or serviced by anyone other than Elite Brands Inc. This warranty covers manufacturer defects as covered by Elite Brands Inc. SOME DEFECTS MAY NOT ALLOW CERTAIN CONSEQUENCES ON THE RESPECTIVE MANUFACTURED PRODUCTS. SO THE ABOVE MAY NOT APPLY TO YOU.

This U.S. Limited Two Year Warranty applies only to ROKINON lenses and accessories registered in the U.S.A. by Elite Brands Inc. and does not apply to international ROKINON products. Elite Brands Inc. may, at its sole discretion, refuse to honor the warranty if any unauthorised product is presented for repair.

THE SPECIFIC WARRANTY BY ELITE BRANDS INC. ONLY WARRANTY WILL APPLY TO THE PRODUCT AND ELITE BRANDS INC. MAKES NO OTHER WARRANTY, REPRESENTATION, OR PROMISE REGARDING THE PRODUCT INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IN ANY EVENT, ELITE BRANDS INC., ROKINON INC., OR ELITE BRANDS INC. SHALL NOT BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL, OR SPECIAL DAMAGES, EVEN IF SUCH DAMAGES RESULT FROM NEGLIGENCE OR OTHERWISE.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This warranty gives specific rights which are in addition to any other rights that may be available under applicable law. ALL RIGHTS RESERVED. ELITE BRANDS INC. CONSIDERS THE ABOVE TO BE THE ENTIRE WARRANTY. ELITE BRANDS INC. 40 WEST STREET, 10TH FLOOR, NEW YORK, NY 10005, USA.  
 Email: support@rokinon.com Phone: (212) 947-7100

Date of Purchase: \_\_\_\_\_ Purchased For: \_\_\_\_\_  
 Name: \_\_\_\_\_ Address: \_\_\_\_\_  
 Phone: \_\_\_\_\_ E-mail Address: \_\_\_\_\_

**ROKINON®**  
 Technology by Samsung Optics

**Certificate of Quality**

Thank you for Purchasing a Rokinon product. Rokinon lenses and accessories are renowned worldwide to deliver the performance required and exceptional value appreciated by both professional and beginner photographer/videographers. This certificate assures that the Rokinon product model and serial number below were manufactured by Samsung Optics in South Korea and incorporates their latest technology, attention to quality and detail.

Director: Seungyoung Anny  
 Quality Control: Park

Rokinon Optics Manufactured  
 by Elite Brands Inc.

40 West Street 10th  
 Floor, New York, NY 10005, USA  
 Email: support@rokinon.com  
 Phone: (212) 947-7100 (Toll Free Worldwide)