

**H4 Plus**  
Helmet Headset

User Manual

Thank you for choosing MOMAN product. Please read this manual carefully before use and follow all instructions mentioned herein.


### Caring For Your MOMAN Product

- Please keep the product in a dry, clean, dust-free environment.
- Keep corrosive chemicals, liquids and heat source away from the product to prevent mechanics damage.
- Use only a soft and dry cloth for cleaning the product.
- Malfunction may be caused by dropping, impact of external force.
- Do not attempt to disassemble the product. Doing so voids warranty.
- Please have the product checked or repaired by authorized technicians if any malfunctions happened.
- Failure to follow all the instructions may result in mechanics damage.
- Warranty does not apply to human errors.

### Package List




H4 Plus Wireless Helmet Headset x1




Speaker with Microphone x1



Back Clip x1



Speaker with Microphone x1




Velcro Clip Kit x1



User Manual x1

### Product Instruction



- |  |  |
|--|--|
| ① Volume Down / Previous Song                      | ⑤ On&Off Key / Play&Pause Key / Answer Key |
| ② AI Voice Keys                                    | ⑥ Charging Interface                       |
| ③ Volume Up / Next Song                            | ⑦ Speaker / Microphone Interface           |
| ④ Indicator ( Working: Green&Blue / Charging: Red) |  |


#### \* Important Notice:

Before installing the headsets, follow the Quick Manual instructions to connect your phone and audition the sound and volume. If there is a large difference in sound effect and volume after installing it on the helmet, please adjust the position of the speaker in the helmet.

### Operation

#### 1. Power On/Off


##### ① Power On



Press and hold for 3 seconds




Power-on tone



The indicator light flashes quickly


##### ② Power Off



Press and hold for 3 seconds




Shutdown tone



The indicator light goes out


#### 2. Pairing



Bluetooth pairing in progress:  
The work indicator flashes quickly



Bluetooth mode tone




Bluetooth pairing successful:  
The work indicator flashes slowly

### 4. Phone Control


#### ① Automatic Answering Mode

Double click to switch between manual/automatic answering. (When Bluetooth is not connected.)



#### ② Manual Answering Mode


Double click to switch between manual/automatic answering. (When Bluetooth is not connected.)




### ③ Redial the last call



### 5. Music control




### 6. Ai Voice Assistant



### 6. Charging mode

Red light on when charging.  
Red light off when fully charged



### Notes

1. Do not put the product into the fire to avoid explosion.
2. Do not dismantle the product to avoid damage.
3. Keep the product away from sharp objects to avoid damage.
4. If not used for a long time, keep the product in a dry place.

### Instruction warning

#### NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference

in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions.

- (1) this device may not cause harmful interference. and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

### Specifications

Connection Distance with Mobile	20m
Bluetooth Version	5.3
Bluetooth Name	MOMAN H4Plus
Bluetooth Protocol	A2DP ,AVRCP
Charging Port	Type-C
Standby Time	360H
Working Time	32H
Battery	3.7V/1000mAh Lithium Battery
Charging Time	2H
Charging Voltage	5V
Speaker Diameter	40mm
Frequency Range	2.4GHZ
Temperature Range	-20~50°C

### Moman (UK) Limited

Unit 25 Basepoint Business Centre, Aviation Park, West Christchurch, United Kingdom BH23 6NX

[www.momanx.com](http://www.momanx.com)

@MomanGlobal

<https://moman.co/youtube>