





User Manual

Thank you for choosing MOMAN product. Please read this manual carefully before use and follow all instructions mentioned herein.





(1) Power & Mode Switch Button

Long press for 3 seconds to turn on/off the product.

When the product is on, short press to switch between 2 light modes, CCT and EFF mode.

2 Dial

Long press down to make a wireless connection.

Roll upwards to increase value, and downwards to decrease value.

3 Brightness Control

For 0%~100% brightness adjustment

4 Type-C DC Input

Used to charge this product and supports 5V 2A input at maximum.

* Charging time varies depending on the power of the charger.

(5) Type-A DC Output

Supports maximum output 5V 2A to power other devices. External power supply will affect the runtime of the product itself.

* Please prepare the corresponding charging cable by yourself to charge other devices. The power management of different devices will control the output voltage and current.


6 1/4" Screw Hole


(7) Cold Shoe

® Display Screen

Wireless Connection:

- 1. Download MOMAN APP (Coming Soon) from our website
- 2. Long press down the Dial on the light to make a wireless connection with






① Color Temperature Control (2500K-9000K):

Roll the Dial upwards or downwards

2 Brightness Control (0%~100%):

Roll the Brightness Control upwards or downwards



- ① In CCT mode, press the Mode Switch Button once to enter EFF mode.
- ② Special effect switch:

Short press down the Dial.

Special Effect: Fire \rightarrow CCT Chase \rightarrow Pulsing \rightarrow TV \rightarrow Explosion \rightarrow Faulty Bulb \rightarrow Welding \rightarrow Strobe \rightarrow Lightning \rightarrow SOS

③ Frequency Control:

Roll the Dial upwards or downwards.

(Note: In SOS effect, frequency control is unavailable.)

④ Brightness Control (0%~100%):

Roll the Brightness Control upwards or downwards.

Specification

Housing Material

Operating Temperature

Dimension

Net Weight

Color Rendering Index (CRI)	≥98
Color Temperature Range	2500K-9000K
Number of bead	60
Display Screen	OLED 23x13mm
Power	8W
Battery Capacity	5000mAh
Runtime	About 125 minutes at 100%
	brightness
Cooling Mode	Passive
Power Input	Type-C
Power Output	Type-A
Input&Output Voltage/Current	5V/2A (Max)
Battery Charging Time	About 3 Hours
Working Voltage	3.7V
Power Requirement	Built-in Lithium Battery /DC Powe

Supply

125x75x17mm

ABS

187g

-10-50°C

Maintenance (

- 1. Please remove the USB charging cable when the battery is fully charged.
- If you do not use the product for a long time, it might not be able to turn on instantly due to dead battery. Please charge the product and it can resume to work. Please charge the product every 3 months regularly.
- 3. Please do not drop and impact the product to avoid scratches on the surface.
- 4. The product is not water-proof.

Notes

- 1. Please do not disassemble or modify the product.
- 2. Please do not submerge the product or put it in fire.
- 3. Please avoid impact on the product.
- 4. This product might become hot during usage, which is normal. Please allow certain space for heat-sink when using it. 5. Please do not put the product in high temperature or high
- humidity condition.

Warranty

MOMAN warrants all its products with a limited 1-year free warranty service.

Please see our homepage for the term in details.

Moman (UK) Limited

- Q. Unit 25 Basepoint Business Centre, Aviation Park, West Christchurch, United Kingdom BH23 6NX
 M. www.momanx.com
- € © © @MomanGlobal
- https://moman.co/youtube