

H1
Helmet Intercom


User Manual

Thank you for choosing MOMAN product. Please read this manual carefully before use and follow all instructions mentioned herein.


Caring For Your MOMAN Product

- Please keep the product in a dry, clean, dust-free environment.
- Keep corrosive chemicals, liquids and heat source away from the product to prevent mechanics damage.
- Use only a soft and dry cloth for cleaning the product.
- Malfunction may be caused by dropping, impact of external force.
- Do not attempt to disassemble the product. Doing so voids warranty.
- Please have the product checked or repaired by authorized technicians if any malfunctions happened.
- Failure to follow all the instructions may result in mechanics damage.
- Warranty does not apply to human errors.

Package List



Product Instruction



- ① Volume Down Button (Short press: previous song / Long press: volume down)
- ② Volume Up Button (Short press: next song / Long press: volume up)
- ③ Intercom Button (Intercom/Charging Indicator Light)
- ④ Type-C Charging Interface
- ⑤ Back Clip
- ⑥ Work Indicator Light
- ⑦ Speaker / Microphone Interface
- ⑧ On and Off Key / Play and Pause Key / Answer Key
- ⑨ Type-C Speaker / Microphone Interface

* Important Notice:


Before installing the headsets, follow the Quick Manual instructions to connect your phone and audition the sound and volume. If there is a large difference in sound effect and volume after installing it on the helmet, please adjust the position of the speaker in the helmet.

Operation

1. Power On and Off / Voice Switching


① Power On and Off

Press and hold the On And Off Key for 3 seconds to turn on/off the device.




② Voice Switching

Double click the On And Off Key to switch languages. (Without Bluetooth connection).



2. Intercom Pairing

Without Bluetooth connection, turn on two intercoms and short press the intercom button of one device to enter the intercom mode and pair. Once the pairing done, the indicator light of intercom button turns green and stays on. After heard a sound like "di", you can talk to your partner by Moman H1.




3. Bluetooth Connection



4. Light On and Off / AI Voice Assistant



5. Music control



6. Charging mode


Red light on when charging.
Red light off when fully charged



7. Telephone Function


① Automatic Answering Mode

Double Click Volume Up Key to switch between manual answer and automatic answer. (When Bluetooth is not connected.)




② Manual Answering Mode

Double Click Volume Up Key to switch between manual answer and automatic answer. (When Bluetooth is not connected.)




③ Redial the last call




8. Intercom reset


① First intercom connection (Without Bluetooth connection)




② Intercom reconnection (Previously connected)



③ Clear the intercom pairing and restore the factory settings (Without Bluetooth and intercom connection)



④ Other helmet Bluetooth headset connection (Without Bluetooth connection)



Notes

- 1.To avoid explosion, please do not put the product into the fire.
- 2.To protect the electronics of the product, please do not disassemble it.
- 3.To avoid accidental damage, please keep the product away from sharp objects.
- 4.If the product is not be used for a long time, please store it in a dry place.

Instruction warning

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no

guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FcC Rules. Operation is subject to the following two conditions.

- (1) this device may not cause harmful interference. and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Specifications

Connection Distance with Mobile	20m
Bluetooth Version	5.0
Bluetooth Name	MOMAN H1
Transmission Range	Up to 500m
Battery	3.7V/1000mAh
Charging Time	2.5H
Standby Time	360H
Continuous Working Time	32H

Moman (UK) Limited

Unit 25 Basepoint Business Centre, Aviation Park, West Christchurch, United Kingdom BH23 6NX

www.momanx.com

@MomanGlobal

https://moman.co/youtube