

H4R
Helmet Headset
User Manual

Thank you for choosing MOMAN product. Please read this manual carefully before use and follow all instructions mentioned herein.


Caring For Your MOMAN Product

- Please keep the product in a dry, clean, dust-free environment.
- Keep corrosive chemicals, liquids and heat source away from the product to prevent mechanics damage.
- Use only a soft and dry cloth for cleaning the product.
- Malfunction may be caused by dropping, impact of external force.
- Do not attempt to disassemble the product. Doing so voids warranty.
- Please have the product checked or repaired by authorized technicians if any malfunctions happened.
- Failure to follow all the instructions may result in mechanics damage.
- Warranty does not apply to human errors.

Package List




H4R Wireless Helmet Headset x1




Back Clip x1



Velcro Clip Kit x1



Changeable hard mic and soft mic speakers x1




Type-C Charging Cable x1



User Manual x1

Product Instruction



- | | |
|--|--------------------------------|
| ① Volume Down / Previous Song | ⑤ AI voice key |
| ② Volume up/Next song | ⑥ Charging Interface |
| ③ Work indicator/RGB Charging indicator | ⑦ Speaker/microphone interface |
| ④ On and off key/Play and pause key/Answer key | ⑧ Buckle Flap |

* Important Notice:

Before installing the headphones, follow the Quick Manual instructions to connect your phone and listen to the sound and volume. If there is a large difference in sound effect and volume after installing it on the helmet, please adjust the position of the speaker in the helmet.

Operation


1. Power On/Off

① Power On



Press and hold for 3 seconds

Voice Prompt



The indicator light on

② Power Off



Press and hold for 3 seconds

Voice Prompt




The indicator light off

2. Pairing



Bluetooth not connected:
The work indicator flashes quickly

Voice Prompt



Bluetooth connected:
The work indicator flashes slowly

3. Phone Control

① Automatic Answering Mode

Double click the Volume up key to switch between manual answer and automatic answer (When Bluetooth is not connected).



Incoming call



After 10 seconds



Answer



Short press



End the call

② Manual Answering Mode

Double click to switch between manual/automatic answering. (When Bluetooth is not connected.)



Incoming call



Short press



Answer



Short press



End the call



Press and hold for 2 seconds



Reject the call

③ Redial the last call



Double-click



Last call redial



Short press




Cancel the call

4. Lights Control



5. Music control



5. Ai Voice Assistant




6. Charging mode

Light on when charging.

Light off when fully charged.

(when the machine is on, plug in the Charger and the machine will shut down automatically).



Notes

1. Do not put the product into the fire to avoid explosion.
2. Do not dismantle the product to avoid damage.
3. Keep the product away from sharp objects to avoid damage.
4. If not used for a long time, keep the product in a dry place.

Instruction warning

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits

are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions.

- (1) this device may not cause harmful interference. and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Specifications

| | |
|---------------------------------|------------------------------|
| Connection Distance with Mobile | 20m |
| Bluetooth Version | 5.3 |
| Bluetooth Name | MOMAN H4R |
| Bluetooth Protocol | A2DP ,AVRCP |
| Charging Port | Type-C |
| Standby Time | 360H |
| Working Time | 32H |
| Battery | 3.7V/1000mAh Lithium Battery |
| Charging Time | 2H |
| Charging Voltage | 5V |
| Speaker Diameter | 40mm |
| Frequency Range | 2.4GHZ |
| Temperature Range | -20~50°C |

Moman (UK) Limited

Unit 25 Basepoint Business Centre, Aviation Park, West Christchurch, United Kingdom BH23 6NX

www.momanx.com

@MomanGlobal

<https://moman.co/youtube>