

**P E L I O S**

**Handheld and Cordless  
Vacuum Cleaner**

**User Manual**



**P E L I O S**  
**Model: K7**

Dear customers,  
Please check the accessories according to the following table.

Name	Quantity
Host	1
Metal Tube	1
Floor Brush	1
Charger	1
Li-ion Battery(22.2V)	1
User Manual	1



Host and Li-ion Battery



Floor Brush



Metal Tube



Charger

# Detail

Separate body for easy cleaning

Remove the battery pack

Switch button


- ① Low grade
- ② High grade
- ③ Closed



Rotate the top and replace the filter

Connect brush head / metal tube

Open the storage



Air outlet



Detachable fluff brush



# Unpacking and assembling

Check the parts in the box

Step 1.

Install the battery as shown in the below picture.




Step 2.

Install the brush by inserting it into the tube carefully.




**Step 3.**

**Install the Metal Tube by inserting it into the vacuum's suction tube.**



**Step 4.**

**Install accessories by inserting them into the vacuum's suction tube (as shown below).**





## Vacuuming floors and carpets

You should regularly check that the nozzle cushions and the brush roller are clean in order to avoid scratching sensitive floors. Follow Steps 1 to 3 to assemble the unit, then start the device by pushing on the On/Off button.

## Vacuuming tables, furniture, car seats etc.

To clean tables, furniture, car seats, or narrow corners; attach a brush accessory (as shown in step 4 above), turn on the power, and start cleaning.

## CHARGING

Before charging, make sure that the vacuum cleaner is turned off. Insert the charging adaptor into a power outlet, then connect the charging cable to the vacuum cleaner.

The indicator light will flash once to indicate that vacuum device has made contact with the charger. It takes approximately 3 hours to fully charge the battery

- the indicator light will turn off once the vacuum cleaner is charged.

If your vacuum cleaner is with charging station (OPTIONAL), there is optional charging method.

Put the battery onto the charging base (well away from heat sources or wet places).

Insert the adaptor into the mains socket and connect the charging station.



# HOW TO EMPTY / CLEAN

1. Press the release button to open the dust cup cover, drop out the trash into the dustbin.



2. Remove attached accessories from the body by pressing the release button. (as shown below)





**3. Remove the dust cup by pressing the release button. Clean the inside components with a small, fine brush or toothbrush. Make sure all parts are dry before reassembling them.**



## **CLEANING AND/OR REPLACING THE HEPA FILTER**

**3. Press the button to open the front cover, then take out the HEPA filter to wash it under flowing water. Let it air dry before its next use. To replace your current filter with a new filter, simply remove the current HEPA filter and install a new one.**



## **REINSTALL THE COMPONENTS**

**After you've removed and cleaned different components of your vacuum cleaner, make sure each part is reinstalled exactly how it was prior to disassembly. Incorrect instalment could cause device damage.**

## HOW TO CLEAN THE ROLLER BRUSH

If the roller brush becomes blocked or jammed for any reason, the vacuum cleaner's suction will be limited. To clean the roller brush, turn off the vacuum cleaner, then carefully use a pair of scissors or a sharp knife to remove any items, such as thread or hair, that are entangled in the brush. If you need to physically remove the roller brush, push on the slip button on the bottom of the brush with a coin or finger. Once you've removed the slip button (as shown below), you can then remove the roller brush entirely for a more thorough clean. When finished, reinsert the roller brush, secure the slip button back into place and lock it by finger.



## Cleaning of wheel axles

If a wheel is jammed by dirt or threads, you can remove the wheels by prying them loose with a screwdriver inserted into the wheel cavity. Remove the threads or any other objects that have become jammed. Once finished, you can reassemble the wheels by pressing them tightly back onto the axles.

## HOW TO STORE THE VACUUM CLEANER

Install the wall mount. When done, you can secure the vacuum cleaner by inserting into the wall mount's hook as pictured.



If you do not have a wall mount, simply place the vacuum cleaner in a corner where it can stand without issue.

