

Three Steps to Programming a PAX S300 Multi-lane PIN Pad With PC America

- 1) Build a file:
 - a. Call PAX for help: (904)900-3741 OR:
 - b. Go to PAX Broad POS: <https://secure.broadpos.com/> to create the file. You will need a User Name and Password.
- 2) Call DATAWIRE: (800)704-4202 to provision an IP Address to associate with the TID.
 - a. Most PAX machines will then download automatically. They will connect with the server using the serial # and IP address.
- 3) To connect equipment to PC America:
 - a. Call PC America: (800)722-6374 OR:
 - b. Go to: <http://faq.pcamerica.com/hardware/pinpad/pax>
 - 1) Choose Heartland Processing or First Data Rapid Connect