


**V400m Bases** The V400m Base provides a stable mounted platform for the V400m terminal. The Base comes in two versions:

- V400m Charging Base
- V400m Full-Function Base


The Charging Base supports charging only with no communication functionality. The Full-Function (FF) Base supports several connectivity options and provides serial connection for peripherals (like ECR, check reader, barcode reader, etc.). The USB host port is for maintenance purpose and supports a USB flash drive.

**V400m Charging Base** The Charging Base accommodates and supplies power to the V400m Plus 3G Base and V400m Plus 4G portable terminals.



**Figure 3 V400m Charging Base, Front and Rear**

**V400m Full-Function Base** The FF Base supports any failover communication via dial up and Ethernet connections for V400m Plus 3G and V400m Plus 4G units. The failover will be supported in all network interfaces available in a terminal.



**Figure 4 V400m FF Base, Front and Rear**