

# **DISCOUNT**

## **CREDIT CARD SUPPLY**

DCCSUPPLY.COM [SALES@DCCSUPPLY.COM](mailto:SALES@DCCSUPPLY.COM) 847-266-1220

### **Vx680 Wifi, Vx680 GPRS Installation Instructions - Device Cover**

#### **CONGRATULATIONS!**

**You have made a great choice to protect your device from germs,  
spills and grime while extending the life of your terminal.**

#### **Instructions:**

1. DO NOT REMOVE THE WHITE MYLAR STRIPS YET.
2. Place the cover on the device, making sure the keypad portion of the cover is lined up with the keys properly.
3. Keeping the cover in place with one hand, remove the front white Mylar strip with the other hand. Secure the front tape down. This is the tape just below the red, yellow, and green keys.  
  
\*If the tape comes off with the white strip, simply reapply the tape to the cover and carefully separate the tape from the white Mylar.
4. Secure the right side next by removing the white strip. Adhere the strip, working from the bottom to the top. This is the side closest to the swiper.
5. Next - flip up the left top corner so that it is sticking straight up. Remove both the left and top white strips. Moving from the bottom left to the top adhere the tape. When you get to the flipped up corner, carefully fold the corner down and adhere the top tape.
6. Check and smooth down any bubbles. You can safely lift up the edge to stretch and reapply the cover.

#### **Tips for Care and Use:**

- This cover is durable but it is made of plastic, so treat it gently.
- Do not use sharp objects or pens as they may puncture the cover.
- Clean with a damp cloth or antibacterial wipe.
- Do not remove the cover to clean it.