

Operating Instructions For Basket Circulation Fans

Caution: Read and follow all instructions before operating. Do not use this fan if any parts are damaged or missing.

Warning: To reduce the risk of fire or electrical shock, do not expose fan to water or rain. To reduce the risk of electrical shock, do not use this fan with any solid state speed control

Rules For Safe Operation

- Never insert fingers or other objects into grill guard while in operation.
- Unplug the fan before moving from one location to another.
- Unplug the fan when removing grill guard for cleaning.
- Do not use with an extension cord
- Do not place fan near open flames or heating appliances
- Do not use the fan in a window or opening that will expose it to rain or moisture which may create an electrical hazard.
- Close supervision is necessary when operating this fan near or around children.


Maintenance

It is extremely important for the life of the fan to keep it free of dust and dirt build up. This is necessary to provide proper cooling to the motor, proper blade balance, and maximum airflow.

No further maintenance is needed.

Mounting Instructions

Attach to ceiling using proper hardware for the structure that will support the mount



Step 1. Attach mount to ceiling in direction of desired airflow using appropriate hardware (not provided).

Step 2. Have one person lift fan up so the mount slides between the yoke brackets on the motor and hold in place.

Step 3. Have a second person place the large bolt through the large hole—using a washer on both sides of yoke bracket. Tighten with nylock enough to hold the fan in place. Tilt fan to desired angle and firmly tighten large bolt and nut.

Step 4. Place small bolt through slot on yoke bracket and ceiling mount. Tighten firmly to hold the angle of the fan.

Operating Instructions For Basket Circulation Fans

Caution: Read and follow all instructions before operating. Do not use this fan if any parts are damaged or missing.

Warning: To reduce the risk of fire or electrical shock, do not expose fan to water or rain. To reduce the risk of electrical shock, do not use this fan with any solid state speed control

Rules For Safe Operation

- Never insert fingers or other objects into grill guard while in operation.
- Unplug the fan before moving from one location to another.
- Unplug the fan when removing grill guard for cleaning.
- Do not use with an extension cord
- Do not place fan near open flames or heating appliances
- Do not use the fan in a window or opening that will expose it to rain or moisture which may create an electrical hazard.
- Close supervision is necessary when operating this fan near or around children.


Maintenance

It is extremely important for the life of the fan to keep it free of dust and dirt build up. This is necessary to provide proper cooling to the motor, proper blade balance, and maximum airflow.

No further maintenance is needed.

Mounting Instructions

Attach to ceiling using proper hardware for the structure that will support the mount



Step 1. Attach mount to ceiling in direction of desired airflow using appropriate hardware (not provided).

Step 2. Have one person lift fan up so the mount slides between the yoke brackets on the motor and hold in place.

Step 3. Have a second person place the large bolt through the large hole—using a washer on both sides of yoke bracket. Tighten with nylock enough to hold the fan in place. Tilt fan to desired angle and firmly tighten large bolt and nut.

Step 4. Place small bolt through slot on yoke bracket and ceiling mount. Tighten firmly to hold the angle of the fan.