




# Wiring Diagram: TH120C

## ⚠ WARNING

**Failure to read and follow warnings may lead to serious injury or property damage.**  
Do not install if product appears damaged.  
Always disconnect power prior to installing, relocating, servicing or replacing thermostat.  
Do not use in potentially explosive or flammable environments.  
Consult a qualified electrician to assist with any questions and/or installation.  
Do not use thermostat in a wet location.  
Installation must be done in accordance with all national and local electrical codes.

### Specifications:

Electrical Ratings: 120v, 16 amp  
Operating Range: 32°F—104°F



### Wiring Diagram

