

Use your PS2 controllers with Xbox One consoles and PC!

This converter is a dedicated PS2 to Xbox One/PC game controller converter. With this converter you can use your different PS2 controllers with your Xbox One console and PC. The converter supports Turbo and vibration functions. The original Xbox One driver (Win 7 or above) is required for use with PC.

- ✓ USB interface which permits hot swapping
- ✓ Vibration support
- ✓ Perfect button mapping
- ✓ Full compliance with all relevant regulations and standards






Game Controller Super Converters Magic Box X1-SBK

PS2 >> Xbox One Controller Adapter



Game Controller Super Converters Magic Box X1-SBK

PS2 >> Xbox One Controller Adapter



Xbox One Gamepad	PS2 Gamepad	PS2 Wired Racing Wheel
DPad-UP	DPad-UP	DPad-UP
Dpad-Down	Dpad-Down	Dpad-Down
DPad-Left	DPad-Left	DPad-Left
Dpad-Right	Dpad-Right	Dpad-Right
A	×	0
В	0	Δ
X		L1
Y	Δ	R1
Menu	Start	Start
View	Select	Select
Lx	Lx	Lx
Ly	Ly	Ly
Rx	Rx	Ry
Ry	Ry	Rx
LB	L1	L2
RB	R1	R2
LT	L2	
RT	R2	X
L3	L3	L3
R3	R3	R3
Xbox Key	ANALOG Key	ANALOG Key

*Press Select + L3 key = PS key function



Connect to Xbox One:

Follow the instructions to connect the converter to the Xbox One console. The LED on the PS2 controller will turn on upon connection.

Turbo:

When the turbo function is used the converter's LED will flash.

Center Button functions:

The Center Button emulates the Xbox button of the Xbox One controller:

- * Press once = Xbox button short press
- Press twice = Xbox button long press
- * Press to wake up the Xbox One if it is in standby mode

Hot swap:

Change controllers without shutting down.

How to assign Turbo function buttons:

Simultaneously press START and the buttons you want to use for Furbo. (Ex: △,O,□, ×, L1, R1, L2, R2, L3, R3)

How to clear Turbo function buttons:

Simultaneously press START and the buttons that currently trigger the Turbo function. (Ex: Δ , O, \Box , \times , L1, R1, L2, R2, L3, R3)