



Scent Diffuser Instructions

Setup

1. To open your Scent Diffuser, rotate the upper half of your device in a counterclockwise motion, while firmly holding the bottom half.
2. Remove the empty oil bottle from the diffuser by turning it clockwise. Save this to use in the cleaning process of your diffuser.
3. Select your Hotel Collection Fragrance Oil of choice and carefully screw the bottle counterclockwise into the diffuser.
4. Once you have securely screwed on the Fragrance Oil, close the unit by sliding the upper half back into place and turning clockwise.
5. Connect the power adapter into the diffuser's power port and plug it into a 110V power outlet.

Important: Make sure the bottle is screwed in tight and parallel to the top half of the diffuser.

Remote Control Functions

Blue LED Light - Indicates the device is powered on

Green LED Light - Indicates the scent is being diffused

Red LED Light - Flashes when any button on the remote control is being pressed

[On & Off] - Powers the device

[Density + (plus)] - Increases aroma's density by 10%. Press 10 times for maximum density

[Density - (minus)] - Decreases aroma's density by 10%. Press 10 times for minimum density

[Aroma] - Starts scenting based on the settings provided.

[Blue Buttons] - Allow you to control the scent concentration by adjusting the scenting interval.

The options are: 20%, 35%, 50%, 65%, 80%, 95%

20% - Diffuser will diffuse scent for 40s and pause for 160s

50% - Diffuser will diffuse scent for 100s and pause for 100s

95% - Diffuser will diffuse scent for 180s and pause for 10s

[1h, 4h, 8h Buttons] - Allows the diffuser to run continuously for a specified number of hours.

1h = 1 hour, 4h = 4 hours, 8h = 8 hours

Resetting Remote to Factory Settings

1. Unplug the diffuser from the power outlet.
2. Hold down the blue button on the remote labeled "35%" for 5 seconds while plugging the diffuser back into the wall outlet. A red light will flash on the diffuser.
3. Avoid pressing any buttons on the remote for 10 seconds as it takes time for the receiver within the device to reset itself.

Tips for Proper Usage

- Avoid windows or air vents so the scent can circulate through the surrounding area.
- Place the diffuser in an area on its own so the scent can flow freely.
- Always position the diffuser upright so the Fragrance Oil can diffuse upward into the air.
- Your Scent Diffuser will only work properly when using Hotel Collection Fragrance Oils. Use of any other oil is not recommended and will void the warranty.
- To preserve the motor of your Scent Diffuser, we recommend running it for no more than 8 hours a day.

Cleaning Your Diffuser

Your Scent Diffuser should be cleaned every 1-2 months and when switching fragrances to ensure optimal performance.

1. Fill the empty oil bottle that came with your diffuser 1 quarter of the way with rubbing alcohol.
2. Screw the alcohol-filled bottle into the diffuser.
3. Run the diffuser for 15 minutes to ensure the alcohol can filter through the whole device.
4. Unplug the device from the wall outlet and keep the diffuser in an upright position. Wipe the device with a damp cloth to remove oil stains and fingerprints. Avoid using any harsh or abrasive cleaning products.
5. Remove the alcohol-filled bottle, insert the Hotel Collection Fragrance Oil of your choice, reconnect both halves of the diffuser and plug it into the wall outlet. You're ready to begin scenting!

Safety

To ensure safe usage, follow these precautions:

- Do not tilt the diffuser as oil can spill inside the device and damage the mechanics.
- Use of the Scent Diffuser and Fragrance Oils requires adult supervision.
- Do not wet the device or place it near any liquids, sinks, bathtubs, or outdoors.
- Do not use the device with any power cord other than the one provided with your diffuser. Position the power cord to prevent it from being a tripping hazard. Before connecting your diffuser to a power outlet, check that the voltage label specified on the adapter is the same as the power supply.
- Do not run the unit on empty. Unless there is oil in the bottle or alcohol for cleaning, turn the device off.
- Do not ingest any Fragrance Oils or apply them to any part of the skin. Keep oils out of contact with eyes, ears, nose, mouth, and any other bodily opening. If contact does occur, flush with water immediately until all traces of oil have been removed entirely from the area.

Replacing the Nozzle

1. To change the nozzle, unplug the diffuser, remove the bottle of oil, and carefully pull out the clear tube. Gently pull out the black nozzle by wiggling it gently using a pair of tweezers.
2. Replace it with a new nozzle and ensure the nozzle is pressed very firmly into the top of the diffuser. The tube can be reinserted into the nozzle. It is very important that you put the tube into the correct opening of the nozzle otherwise the unit will not diffuse scent. Within the nozzle there is a small round tube holder that the tube needs to be firmly secured into.

Tip: If you are having difficulty seeing the tube holder inside the nozzle, hold a flashlight into the nozzle to increase visibility.

Disclaimers

- The Scent Diffuser comes with a 90-day limited warranty.
- All Hotel Collection diffusers are specifically designed to be used with Hotel Collection Fragrance Oils. Using any other oils, adding water, or any other misuse of the diffuser will void the 90-day warranty.