




## How to vent a heated towel rail (bleeding)



1 Unscrew the screw that we find on the upper part of the towel warmer, add themissing liquid (water).



2 Switch on the article and let it "breathe" for about an hour. The article willremain without the screw, it will let some liquid flow into excess. (you could put some paper "scottex" around so as not to let the liquid drip on the floor).



After 1 hour, close the towel warmer with the screw removed in precedence.