

VUSH™

SHINE

INTERNAL G-SPOT VIBRATOR CARE AND INSTRUCTION MANUAL


HEY BABE, COME HERE OFTEN?

Welcome to your self love journey! We're so excited to introduce you to Shine!

Shine is the G-Spot vibrator that will completely rock your world. It's time to explore your body in the best way possible and Shine is your new helping hand!

With 10 vibration settings to help you get to that big O and curves in all the good spots to help you reach your great spot, you'll be shining all day + night!

CHECK ME OUT



YOU'RE IN CHARGE

Before we can get down to the good stuff, your Shine will need to charge for 2 hours. Your charger will be in the lid of the toy tube. Insert the main USB plug into any USB port.

IN CASE CHARGING

Connect the charger with the charge port on your Shine case (those two fancy silver dots). Ensure the charge dots on the toy are lined up with the two on the inside of the case.

DIRECT TOY CHARGING

Connect the charger with the charge port on your Shine (those two fancy silver dots).

You'll feel a slight pull and a click, followed by your Shine LED light flashing to let you know it's charging (just above the 🔌!). Catch up on that show you've been meaning to watch - it won't be long! The LED will stop flashing when your Shine is ready to play.

We recommend only charging your Shine with the provided VUSH charger.

TURN ME ON

Charge Shine for 2 hours to reach full charge. Hold down 🔌 for a few seconds to turn on. Press 🔌 to search through the 10 settings. Make some magic! Press and hold 🔌 to turn off.

PLEASURE TO MEET YOU

Settle in, get comfortable, and turn on your Shine. Choose your fave starting level. Shine is perfect for g-spot, and overall external stimulation.

For clitoral + external stimulation: Position the pleasure point over your selected area and try different levels, patterns, and pressures to find how to best love yourself!

For g-spot stimulation: Everyone's anatomy is different, but the g-spot is usually located about an inch inside the vaginal opening on the upper wall. We recommend external stimulation first before taking the dive. You should be looking for a firm, pressing sensation when you're ready.

Lubrication: If you'd like extra lubrication for your Shine, you can apply as much as you need to the head. It's important to only use water-based lubricants with your Shine. Other oils, creams, or silicone-based lubricants can damage the high-grade silicone of your toy over time.

GOOD CLEAN FUN

Always clean your Shine thoroughly before and after each use. It's waterproof, so simply wash with clean water and unscented soap, then rinse and refresh with Clean Queen Intimate Accessory Spray for additional protection. Pop Shine back in its case once dry - ta da!

For those times when you need something quick and discreet (like when your roommate is using the bathroom for karaoke practice), you can also use a gentle wet wipe, like VUSH You Do You wipes.

Show your Shine a little more love and care! Always store Shine with its lid on, to avoid dust build up or damage from other materials, and to keep it safe from sunlight or other extreme heats.

SAFETY FIRST

Shine is for adult use only. Keep out of reach of children. Those who may be pregnant, have a pacemaker, diabetes, phlebitis, thrombosis, or any other condition, should consult with a medical professional regarding the risk of blood clots before using any personal massage product.

Do not use on areas that have pre-existing injuries or on swollen skin. For some, excessive use of vibrating devices can cause temporary numbness and loss of sensitivity. If this happens, take a break and treat yourself to another self love practice.

If pain occurs please cease use immediately. Consult a doctor before use if you have any implanted devices, such as a pacemaker, or if you have had any form of surgery on the relevant body parts. VUSH assumes no responsibility for misuse or excessive use of this product. Always switch off after use.

DISPOSAL ADVICE

Dispose of according to your local regulations.

SPECS

PRODUCT SIZE: 165 x 45mm	POWER INPUT: 5V
MATERIAL: Medical grade silicone/ ABS Case	BATTERY TYPE: Flexible polymer lithium battery
PRODUCT WEIGHT: 154g	FREQUENCY: 10 modes
WATERPROOF: IPX7	BATTERY CAPACITY: 420mAh
CHARGE TIME: 120 minutes	WORKING CURRENT: ≤350mA
USE TIME: 70 minutes	MOTOR SPEED: 800RPM ±10%
NOISE: Less than 50db	INTERFACE: Single button
LOW BATTERY WARNING	MAGNETIC CHARGING

WARRANTY

We provide a 1 year customer warranty from when you first purchased your product. After 1 year from your initial purchase we have no obligation to send you replacement items even if previous ones were sent.

We recommend familiarizing yourself with our Terms and Conditions via vushstimulation.com/pages/warranty-refund-policy

GET IN TOUCH

Vush Pty Ltd
Level 1 East, 170-180 Buckhurst Street,
South Melbourne VIC 3205 AUS
Website: vushstimulation.com
Support: info@vushstimulation.com

FOLLOW OUR MOVEMENT AND
EMBRACE #MORESELFOVE

 VUSH_OFFICIAL

All trademarks are property of Vush Pty Ltd
Designed in Australia, made with love in China

