

South Bend® 37" x 53" Downdraft Table

FEATURES

- · Heavy-duty steel-frame construction
- · Removable table boards
- Internal V-bottom for directing air flow
- · Adjustable table height
- Two 4" dust ports
- · Ledge allows you to sand edges of boards
- US based customer service and technical support

SPECIFICATIONS

- Table size: 37" x 53"
- Shoulder Table Size: 6" x 53"
- Table Height Range: 26"-43"
- · Dust Port Size: 4"
- · Load Capacity(Per Suction Board): 40.5 lbs.
- Minimum airflow required: 1500 CFM
- · Weight: 140lbs.

Made in an ISO 9001 factory



Heavy-duty steel frame construction for long-lasting durability.



Features two 4" ports for your dust collection system.

AN ECONOMICAL AND PRACTICAL SOLUTION FOR CAPTURING DUST

Even the best handheld sanders with built-in dust collection are not 100% efficient. A downdraft table captures this excess dust thrown out from the sander and into the air.

Whether using a random orbital sander or sanding by hand, a downdraft table connected to a dust collector is the absolute best way to ensure a dust-free environment.

The South Bend 37" \times 53" Downdraft Table features heavy-duty steel-frame construction for long-lasting durability and removable table boards for flexibility.

It has over 13-1/2 square feet of table surface area with an internal V-bottom that directs air flow down through the table and into your dust collection system at the two 4" dust ports (one at each end).

The unique shoulder step on the table sits 1-1/2" below the center of the work table for efficient edge-sanding of boards. The table height can be adjusted from 26" to 43" tall.

1500 CFM is the recommended minimum airflow for this downdraft table.

BUILT TO TRUE SOUTH BEND HIGH-QUALITY INDUSTRIAL STANDARDS

The instructions were written by our U.S.-based Technical Documentation Department and are packed with useful information. The easy-to-read instructions explain how to assemble and maintain your downdraft table.

The South Bend Customer Service and Technical Support Teams are U.S. based. Parts and accessories for the downdraft table are available on-line and shipped from the South Bend parts warehouse in Springfield, MO.

WARRANTY INFORMATION

South Bend Tool Company warrants every product it sells for a period of 2 years to the original purchaser from the date of purchase. We make every effort to ensure that our products meet high quality and durability standards so that you never need to use the warranty. Please feel free to write or call us if you have any questions about the machine or the manual.

For more information visit www.southbendtools.com/pages/warranty