




B.O.G. Fuzz



Fuzz




Level



1. Footswitch operates the B.O.G. Fuzz. On when the LED is lit.
2. Adjust the amount of Fuzz.
3. Adjusts the level (Volume) of the B.O.G Fuzz

B.O.G. Fuzz Connectors

Rear View



+9V PWR: Standard effects pedal power; 9V centre negative.

In: Connect your instrument or other pedal to this socket.

Out: Connect this socket to your amplifier or next pedal.