


User Instructions

Villa Pergola motorized operation Size: 13'x19' Double Bay (400 x 600cm)



Content

Tools and man force	1-2
Parts List	2-5
Product Description	6
Safety Instruction	6-7
Mounting	8-17
Dismounting	18
Storage	19
Disposal	19



Attention:

Read this instruction manual carefully and completely before mounting and usage. Keep this manual for future reference.

Dear Customer,

Congratulations and welcome to our Villa Pergola family. To enjoy your Villa Pergola for its lifetime and for you and other's safety, please follow the assembly instructions.

Before you start the assembly process and using the Pergola, we suggest you are best to get familiar with this product. Make sure all parts listed up in below packing lists are delivered and intact. If you find that there are parts missing or damaged please do not install the pergola but contact us immediately. Do not start the assembly process if parts are missing or defective.

Tools and man force


Recommended: 2 or 3 people


Additional tools:

1.Ladder 2. M10/13 open wrench supplied 3.Rubber mallet

4. Tape measure 5. 5mm hexagon wrench supplied 6. Pencil

7.Spirit level 8.Electric drill







Parts List

Please check all parts against the parts list before commencing construction of pergola.

SIZE: 13'x19' or 400X600CM (double bay) PARTS LIST





Aluminum profile parts list:

(A1) Beam	(A2) Beam
(B1) Beam	(B2) Beam
(C1) Beam	(C2) Beam
(C3) Middle Beam	(D1) Post + post connector
(D2) Post + post connector	(D3) Middle Post + post connector
(E1) Gutter	(E2) Gutter
(F1) Gutter	(F2) Gutter
(G) Common Louver	(H) Steering Louver
(I) Strenthen Louver	(J) Steering profile

Hardware and other parts:

② M8x20 countersunk screw	250 to 40 connector	③Base plate
4 Upright cover	⑤M10 screw cap	⑥M8x20 Hexagon bolt
⑦Plastic washer DAP25	⑦Locking nut	Motor with motor bracket
(10) Gutter connector	①wall bracket	12 Slider
13 L-Bracket	① Cover plate	15 M8X100 Internal anchor
16 M8X100 Anchor	17 Base plate caps	

Product Description

Make the most of your outdoor living area with your pergola. Relax and enjoy the outdoors while being protected from sun. The coated aluminum frame pergola is perfect for shading your garden, deck, courtyard and swimming pool.

Important Safety Instructions

Warning: For the safety of you and other persons it is important to follow below instructions and obey warnings.

Symbol explanation



This warning triangle calls attention to hazards that that can lead to death or to severe injuries or which are important for the functioning of the Pergola.



This sign identifies important notes.

Safety instructions



To install this pergola technical knowledge is necessary. Do not mount this pergola yourself but contact a professional workman for help if

- you are unsure if the pergola can be mounted on the place you chose for installation.
- you do not understand the instruction manual or parts of it.
- you do not have necessary tools available.
- you do not have necessary technical knowledge



A minimum of three healthy adults are required to move and install the pergola as the product is big and heavy. Do not try to install the pergola alone. If the pergola falls, it could cause serious injuries and damages! Contact an authorized assembler for help.



Do not install the pergola when you find damage parts are that parts are missing. Contact your dealer.



Keep children and pets out of the working area during assembly and adjustments.



This product and its fixing parts are only suitable for installation on a plain cement wall or stable brickwork. If the wall/brickwork shows cracks you have to consult a professional.



Nobody is allowed to change the products' design and structure without the permission of manufacture or authorized deputy.



Please make sure that your hands are clean at the time of the assembly; otherwise you may soil frame.



Nobody is allowed to climb onto the Pergola. Hanging anything on the Pergola is forbidden.

Sheeting was used to protect the paint. This must be removed afterwards.

This structure is a non-permanent structure and the warranty does not cover damage incurred under extreme weather conditions including heavy rain, high winds or if exposed to high heat from heaters or BBQs.

Safety precautions should always be followed when assembling and using this product to reduce the risk of personal injury and damage to equipment. Please read all instructions before assembly and use. Never leave children unattended around/under this pergola. Do not attempt to assemble or use the pergola in moderate or heavy wind conditions. Always **keep the pergola louver open** and secure it during heavy winds or extreme weather conditions to avoid damage to the pergola or personal injury.


Mounting and usage

Step 1


Attach base plate 3x3 to the bottom of posts (D1 /D2/D3), use bolts 1x12 to attach with hex key or electric drill.

D1 ,D2, D3 posts should be installed diagonally as below.

Please make sure all posts on the same horizontal plane.




Step 2
According the height of ©2 to measure the height of 15, use anchor to fasten




Use bolts $(2) \times 6$ to fasten beam $(3) \times 6$ beam $(3) \times 6$.

12 x6	
B1 x1	Į.
B2 x1	12




Step 4

Insert the A1 / C1 into D1 ,then connect B1 with 13 ,fasten the screws.




Step 5


Connect A2/B2 with 3 , fasten the screws,and insert the middle beam C3 Lock the screws




Step 6 Connect the B1 and B2 , insert C1 into O3 , fasten the screws.



Step 7
Cover the post with 4 x2, fasten the screws.




Step 8 Cover the beam on both sides with 4, fasten the screws




Step 9


Placed all gutter E1 , E2 , F1 , F2 in proper position as picture



Fasten ①x2 gutter connector and ②x2 50 to 40 connector. Connect the female and male plugs for the LED lighting, (DC24V to DC24V) and motor (DC24V to DC24V) and plug the power cable into local socket.



Step 11
Fasten motor 9x2 as shown below.



Place center louver ① into 16th slot, lining up with the holes
Using M10 nut ⑤ X2, secure the louver in place
Place Steering louvers ① X2 in line with 7th slot on the beam ② and ②.
Fit all common louvers ⑥ X58 into the remaining slots in the beams


	9
⑤ x58 ℍ x2 ① x2 □ 1	
⑤ x2 🎅	
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	,
(5)	
	0
````	
```	~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~ ~
H)	
	G H
	(5)
₩	
(H)	

Fix ①x 4 (flat L-shaped aluminum profile).

One for each other of the slats is required.

Use bolt ⑥ x124, plastic spacer⑦x124 and nut⑧x124 to tighten for 600X400cm size. Secure the louvers at each end.


NOTE: Do not over tighten. Over tightening will prevent louvers from moving.



Mark holes for expansion bolt 6x12 on each post.

Note the drill size should be 12 mm.


Insert the bolts. Use an hammer drill if necessary. Place the posts over the bolts. Tighten the nuts. Once installed, make sure any remaining plastic is removed and silicone is used along all corners and gutters to waterproof.



WARNING: Make sure louvers are open when mild to strong winds occur for safety.

Motor setup

86 operation instructions for DC controller with lamp control



1. Product characteristics

- Exquisite and unique appearance design;
- ▶ 86*86 national installation standards;
- Using impulse current relay;
- ▶ Adopting precision SMT process, surface moisture-proof treatment;
- Parts of electrical apparatus meet the requirements of fire safety standards for electrical standards;
- Power supply safety protection, the power output time is 5 minutes:
- Cooperate with all kinds of launchers and tubular motors.

2. Product parameters

Product model	ZC31-03-2AD
Input voltage	AC100V-240V
Load power	Lamp≤500W Motor≤48W
Receiving / transmitting frequency	433.92MHz
Working temperature	-30℃~+65℃
Receiving sensitivity	-110dBm
Number of transmitters allowed	≤8 pcs
Operation mode	Remote / manual control


▲ Installation notes

- ➤ The main power source must be cut off before installation.
 ➤ Transmission distance≤80 metres.

 ➤ Maintain a distance of 0.5 meters between receiver and ground.
 ➤ Maintain a distance of 0.3 meters between receiver and ceiling.
- Please use soft wire and soft cable.
 Please use soft wire and soft cable.
 Please avoid electrostatic interference, otherwise, it will damage the components.
 Ensure that cable carriers are not affected by longitudinal forces after installation.

3. Product wiring

Lamp controlled DC receiver ZC31-03-2AD 665 66 60 WSR SENSOR MOTOR LEN Motor



Dismounting

If you want to disassemble the Pergola, please follow the following process.

Attention! At least two people are needed for this step.

- Keep the Pergola louvers open before you begin with dismounting. Bind the Louvers of the Pergola together to avoid unintended unfolding. This might cause damage and injury. You can use the protection band that was fixed on the Pergola when purchasing it.
- Follow the mounting instructions in reversed order to dismount the Pergola.
- Make sure that drilling holes in the wall will be sealed professional.
- Attention! Safety hints and instructions have to be followed for dismounting as well.

Storage

When you do not want to use the Pergola for a longer period of time it is recommended to take the Pergola out of the brackets and store it.

- Make sure that the frame is dry completely before storing.
- Store the Pergola at a dry and safe place that is not reachable for children.

Disposal

Do not dispose this Pergola with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling. Dispose packing materials according to local guidelines.