


ARMANOV

Recoil Spring Gauge


Instructions for use




Armanov d.o.o.
Brezovce 9
1236 Trzin, Slovenija
Tel: +386 30 467 000
armanov.com




- ① Insert spring guide bolt through recoil spring of your pistol. Insert both into hexagonal hole in the bottom of gauge body and through round hole on top.
- ② Screw nut about one full turn.



- ③ Insert hook attached to digital scale through hole in the nut.
- ④ Turn on the scale and set desired unit (usually lbs).
- ⑤ Slowly pull handle of the gauge body and strap of the scale using both hands.



- ⑥ Align upper side of the bolt head (end of spring) with the notch mark for the desired pistol.
- ⑦ Read spring power on the scale's display.



Compatibility:

- CZ Shadow 2
- CZ 75 Tactical Sports
- CZ 75B, SP01
- Tanfoglio Stock 2, 3
- 1911 5" barrel
- 2011 5" barrel
- Beretta 92FS