ASSEMBLY INSTRUCTIONS



Item No: D1651-20 (Oscar Wood Back Chair)

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items and compare with the parts list and/or hardware list shown below.


PARTS LIST					
NO	DESCRIPTION	SKETCH	QTY		
1	LEFT SIDE FRAME (L)		2PCS		
2	RIGHT SIDE FRAME (R)		2PCS		
3	FRONT STRETCHER (A)		2PCS		
4	BACK STRETCHER (B)		2PCS		
5	TOP REST		2PCS		
6	CUSHION SEAT		2PCS		


	HARDWARE LIST					
	NO	DESCRIPTION	SKETCH	QTY		
	Α	JCBC M6 x 25mm + S/W M6 + F/W M6 x 13mm		8PCS		
	В	JCBC M6 x 45mm + S/W M6 + F/W M6 x 13mm		8PCS		
	С	ALLEN KEY M4		1PC		
	D	L BRACKET	S	8PCS		
	Е	PH SCREW M4 x 12mm	«uu®	16PCS		
	F	WOOD DOWEL M8 x 25mm		4PCS		
	G	WOOD BUTTON 14.5mm	0	8PCS		


CAUTIONS:


STEP 3


- (1) DO NOT FULLY-TIGHTEN THE NUT OR NUT
 BOLTS INITIALLY UNTIL ALL NUTS OR BOLT IS
 READY ASSEMBLED.
 - (TO AVOID CAUSING DAMAGES TO THE THREAD, DO NOT <u>OVER-TIGHTEN</u> THE NUTS OR BOLTS.)
- (2) KEEP ALL HARDWARE PART OUT OF REACH OF CHILDREN.

















CHAIR ASSEMBLY.