P.RIDE - QUICKSTART*

Individual Mode / First use

- Open the zip fastening on the shoulder strap.
 Move the handle to the horizontal ON position to activate the system.
- An automatic system and battery check is carried out. You can tell that it was successful when the top LED flashes green every 3 seconds.
 If you pull the activation handle, only your own airbag will be deployed.
- If the top LED flashes orange the battery charging status is at 20% or below. The battery should be charged.
- 4. If the top LED flashes **red** the P.RIDE system is not operational.

Group Mode

- 5. To create a group all group members move their activation handle at the same time to the ON position within an activation field of up to 10 m. When the green LED lights up (after approx. 2 seconds), press the function key.
- If the grouping and the system test was successful the top LED blinks green and the bottom LED blinks blue.
- If a group member pulls his/her activation handle, every airbag in the group will be deployed.
- If you want to leave the group, move your handle into the OFF position and then press the function key. This is confirmed by two red LEDs.

^{*}Tip: It is recommended to print, laminate and to put in the hipbelt pocket.

Single Mode

- If one person wants to ski a slope alone, he
 or she can activate single mode by pressing
 the function key. The bottom LED on
 his/her system flashes blue quickly. The
 bottom LED flashes blue twice every 3
 seconds for the rest of the group.
- 10. This function allows the airbags of the single skier to be activated without activating the airbags of the other group members. To do so one group member pulls the activation handle with the function key pressed down.
- If only the single skier pulls the activation handle him/herself, only his/her airbags are deployed.

12. If a group member pulls the activation handle without pressing the function key, the airbags of the single skier and the entire group will be deployed.

