

EASISOLV 722

SCREEN WASH & STAIN REMOVER

EasiSolv 722 Screen Wash & Stain Remover is designed to dissolve silicone ink from the screen printing mesh before removing the emulsion. This product is applied to the screen printing mesh and rinsed with water. It also contains surfactants that degrease the screen printing mesh when used as a final step in the reclaiming process. 722 is an Easiway approved stain remover, dissolving silicone stains, emulsion residue and stains and ghost images from the screen printing mesh. This product does not contain APEO, making it compliant with many restricted substance lists; including Nike, Gildan, VF, Levi Strauss.

Appearance:	Clear, amber
Odor:	Mild
Ph:	N/A
Flash Point:	68°C / 155°F
Specific Gravity:	0.88 @ 20°C / 68°F
Weight/gl:	6.4 lbs/gallon
VOCs:	
Dot Shipping:	Non-hazardous

Quart	
Gallon	722-1 GL
5 Gallon pail	
55 Gallon Drum	722-55 GL

STORAGE REQUIREMENTS

Keep the container tightly closed. Store in a dry, cool and well ventilated place away from incompatible materials such as caustics.

PRODUCT FEATURES

- Best for silicone stain removal
- Contains degreasers
- Will not foam

APPLICATION/USE

Scrape excess ink from screen. Apply EasiSolv 722 to the (well) ink and print side of the screen. Scrub if necessary. Squeegee excess off screen. Using a good high pressure washer, spray rinse the screen starting at the bottom of the well side and work up. Give good attention to the image area of the screen. Rinse the print side of the screen. Apply an Easiway Systems approved emulsion/stencil remover. The screen will now be ready for reuse. (no need to use an additional degreaser)

COMPATIBLE INK TYPES

- Silicone