

BECAUSE WHO WANTS TO SPEND ALL DAY CLEANING DIRTY SCREENS?



DIVE INTO THE EASIWAY DIP TANK METHOD

Is reclaiming screens taking up too much of your time? We hear you. Follow this guide to streamline your screen cleaning routine and get back to what matters most — creating amazing prints!



DIP & DWELL

RINSE & BLAST

- Remove tape and scrape off excess ink.
- This prevents gunk build-up and ensures optimal cleaning.

PREP LIKE A PRO

- Submerge the screen in the dip tank filled with a pre-mixed solution of EasiStrip™ Supra (1 part) and water (7 parts).
- Let it soak for 30 seconds to 1 minute, allowing the solution to break down ink and emulsion
- Pull out the screen, tilting it to drain excess solution back into the tank.
- Blast both sides (substrate side first)
 with a high-pressure washer to remove
 loosened ink & emulsionwasher to
 remove loosened ink & emulsion.







FINAL TOUCHES

- Spray both sides with EasiSolv™ 701N, our all-in-one screen wash, stain remover and degreaser.
- Use small circular motions to scrub any remaining ink or stains. This powerful formula tackles even the toughest residues.
- Power wash the screen again to ensure a spotless clean.

RINSE

- · Thoroughly rinse the screen.
- End with a low-pressure flood rinse until all bubbles are gone and water flows smoothly.

INSPECT & DRY

 Hold the screen up to a light source to confirm a 100% clean surface.

TACKLING TOUGH STAINS

For those extra-stubborn stains that just won't budge, we've got you covered:

After **step 4**, apply **415N Stain & Haze Remover**, let it sit for 5 minutes, and then power wash the stain away.

SUPPLIES

- EasiStrip Supra Ink and Emulsion Remover
- EasiSolv 701 screen wash, stain remover, and degreaser
- EasiSolv 415N Stain and Haze Remover
- Scrub pad