

THE EASISOLV SPRAY SYSTEM

ESS-1 INSTRUCTIONS



1. Place 3/8" line through the 3/4" drop tube and replace the coupler on the end of the 3/8" line, and attach to pump.



2. Place the drop tube/line into drum (pulling foot valve tight against tube) gently thread bung cap into place.



3. Make sure the ball valve on air inlet is closed and attach the air line.



4. SLOWLY open ball valve let the air pressure slowly build up, as this will prime the pump. (Never take the pressure over 50 PSI.)



5. Attach air source to pump regulator. (Note: the gauge and regulator are preset, pump should be run at no more than 40 PSI.)



6. To use, pull trigger back to prime pump and apply spray to screen.