












- 1. Remove exisiting spool until you have only the spindle exposed.
- 2. Slide the LJ adapter onto spindle (only required for a long spindle for a short spindle attach the base straight onto spindle)
- 3. Attach LJ base and spacer with the appropriate nut or bolt inside the base (inculded in your pack)
- 4. Tigthen the nut or bolt until secure, this is now centralised to the machine.
- 5. Attach the LJ head along with the LJ nylon line reload in the holes provided and screw to lock in place. Double up your nylons through the one hole for better cutting power and durability.



Parts in your Littl' Juey pack



Load your nylons that suit the job and power of your machine. The best option is doubling up your nylons through the one hole for optimum cutting power and efficiency.



HOT TIP!

Use your offcuts of nylon and thread through the Littl' Juey head and tighten. NO WASTAGE OF NYLON!

NYLON IDEAL USAGE:

- 2.4mm Standard Nylon 1 line or double up through the one hole
- 3.2mm Heavy Duty Nylon 1 line only would be needed.

