

HOW TO GET THE BEST PERFORMANCE FROM YOUR SAWYER FILTER

1. Backflush Often

This will help keep it flowing faster

2. Backwash Forwards and Backwards if it's really clogged -

Pushing clean water forwards through the filter helps loosen up more dirt/silt.

3. Don't Over Tighten the Filter on your pouch or bottle -

This is what causes the gasket to fall out. Just hand tighten.

4. Keep it protected in freezing weather -

If temps are below freezing keep your filter in your jacket or sleeping bag.



SAWYER®

