## FIXNZIP™ NICKEL ZIPPER SLIDERS

Instant zipper repair without tools, sewing or angst.



FIXNZIP™
LARGE NICKEL ZIPPER SLIDERS

### **Dimensions**


Packed Size:

9.6cm (W) x 1.8cm (D) x 15.3cm (H)

**Product Size:** 

1.8cm (W) x 4.2cm (D) x 2.2cm (H)

Net Weight: 28gm



FIXNZIP™
SMALL NICKEL ZIPPER SLIDERS

### **Dimensions**

Packed Size:

9.6cm (W) x 1.8cm (D) x 15.3cm (H)

Product Size:

1 cm (W) x 3cm (D) x 1.3cm (H)

Net Weight: 28gm



FIXNZIP™
MEDIUM NICKEL ZIPPER SLIDERS

### Dimensions


**Packed Size:** 

9.6cm (W) x 1.8cm (D) x 15.3cm (H)

**Product Size:** 

1.8cm (W) x 3.5cm (D) x 1.3cm (H)

Net Weight: 28gm



FIXNZIP™
3 PACK NICKEL ZIPPER SLIDERS

### Dimension

Packed Size:

9.6cm (W) x 1.8cm (D) x 15.3cm (H)


**Product Size:** 

1.8cm (W) x 4.2cm (D) x 2.2cm (H)

Net Weight: 85gm



The Oztent Group is the sole distributor of FixnZip™ products to the outdoor and camping market in Australia. Please contact 1800 OZTENT (698 368) or email: service@oztent.com for more information.



## FIXNZIPTM **NICKEL ZIPPER SLIDERS**

Instant zipper repair without tools, sewing or angst.

Broken zip?

FixnZip™ fixes almost any zip, on anything, anywhere, anytime!

Keep your zippers in perfect working condition with FixnZip's Zipper Sliders - to repair or replace stuck or busted zip tabs in seconds.

Various kitts available to work with all size of zippers, regardless of the brand.

Simply secure the fastener to the zipper teeth and zip away. Keep a Fixn-Zip™ Zipper Slider close at hand to ensure your zips work smoothly.

## **KEY FEATURES**

No tools or sewing required Removable & reusable Fits large zippers of all types High quality slider Used by the military

## **SPECIFICATIONS**

Material Nickel Plated Zinc

## **DIMENSIONS**

Please see back page

Packed Size: 9.6cm (W) x 1.8cm (D) x 15.3cm (H) Product Size: 1.8cm (W) x 4.2cm (D) x 2.2cm (H)

Net Weight: 85gm

1 Yr

# NICKEL ZIPPER SLIDERS

Instant zipper repair without tools, sewing or angst.

## STEPS TO FIX OPEN END ZIPPERS (ex.: jackets)

## STEP 1

The screw on the FixnZip® slider should be toward the outside of the item.



STEP 4

Place slider close to zipper box. Tighten the screw all the way

down, then loosen 1/4 turn


STEP 2

Loosen the screw on the slider.




## STEP 5

Slider should now be tightly secured to one row of teeth, like you would find on an




## STEP 3

Slip the slider over one row of zipper teeth.



## STEP 6

Insert zipper into the slider, and zip up the jacket.



## STEP 4

Feed both rows of teet into the slider close to the

STEP 6

Squeeze the top and bottom of slider at the same time. With your

other hand, firmly grasp the




# STEP 5

While still

## Tighten thumbscrew all the way


## STEP 7



## STEPS FOR INVISIBLE/WATERTIGHT ZIPPERS

Determine if you have an invisible/ watertight





When applying the FixnZip®









