

### Bridger Cummerbund Sizing Chart

The sizing chart below explains the internal circumference you will have with different size bases. Measure waist around at the naval to size. You must also give allowance on size if you plan on running side plates or inserts. Clothing must also be accounted for in your sizing.

Size	Length of Each Side
Medium	18.5"
Large	20.5"

Medium ESAPI Base Used		
	Minimum Length	Max Length
Medium Cummerbund	39.5"	46"
Large Cummerbund	42.5"	49"

Large ESAPI Base Used		
	Minimum Length	Max Length
Medium Cummerbund	41"	47.5"
Large Cummerbund	44"	51"