

Instructions For TX4/MPS/DPS/SDO21/12

- ◆ Locate the Learn/Code Set button on the motor. This is usually under the lamp cover or on the back of the motor
- Press the Learn/Code Set button once and immediately release the button. A light on the motor will illuminate.
- Press the button on the new remote that you wish to operate the door once. The light on the motor will extinguish.
- Press the same button on the new remote a 2nd time. The light on the motor will begin to flash rapidly.
 Once the light stops flashing, press the button on the new remote a 3rd time to test the operation of the door.

If the remote did not successfully code to the motor and you only get a continuous flashing light on the motor, you may have held the learn button down too long. To correct this, open and close the door 4 times using an existing remote, then try to code in the new remote again.

WARNING

This product may contain a coin/button cell battery. Keep product and batteries away from children. Battery can cause severe or fatal injuries in 2 hours or less if swallowed or placed inside any part of the body. Seek immediate medical attention if it is suspected that a coin/button battery has been swallowed or placed inside of any part of the body.