




# FlexLamp™

## User Guide for Model PL5002

### CAUTION – RISK OF PERSONAL AND PROPERTY DAMAGE

- Do not connect the product to a computer, as the high charging current could damage the computer.
- Do not use if there is visible damage to the product or the connection.
- Do not cover the product during operation, and ensure that there is sufficient air circulation.
- Protect the product from: impact, direct sunlight, sub-zero temperatures.
- Do not place any heavy objects on the product or its connection.
- Lay the connection in such a way that it is not crushed or bent and does not come into contact with hot surfaces.
- Turn off and unplug the product immediately in case of damage or malfunction.
- Unplug the power adapter from the outlet before a storm.
- Only use original accessories from the manufacturer so as not to impair the functioning of the product and to prevent possible damage.
- To protect the surface, do not use corrosive or abrasive cleaners. Wipe the product with a damp cloth as required. Then dry it off.

### Product Overview



1. Touch Button
2. Lamp Head
3. Light Panel
4. Lamp Post
5. Lamp Base
6. Charging Port (Type-C)
7. Flexible Goose neck
8. Status Indicator

### Before First Use:

1. Remove any packaging films, stickers or transport protections from the product. **Never remove the Rating Label!**
2. Assemble the FlexLamp according to intended usage (Floor Lamp, or Desk Lamp), see next page for assembly instructions.
3. Charge the battery (see the chapter “Charging the battery”).

### Customer Service / Importer:

QX Brands, Marietta GA 30068 USA  
 2021 QX LLC | All Rights Reserved.  
 +1-678-404-9426 | [www.qxbrands.com](http://www.qxbrands.com)

### Charging the Battery:

- Use a USB power adapter that has an output current at least 1A. **Do not use a computer USB port to charge!**
  - Make sure the power outlet the USB power adapter is plugged into has been properly installed. The outlet should be easily accessible, so that the charger can be quickly disconnected if needed.
1. Connect the USB cable to the lamp’s Charging Port (6) and a USB power adapter (Not included).
  2. Plug the USB power adapter into a power outlet. The Status Indicator (8) will flash red slowly (“breathing”) while the lamp is being charged (Lamp is off). It will change to solid green when the battery is fully charged.
  3. After charging, unplug the USB power adapter from the outlet and then the USB cable from the lamp’s Charging Port (6).

### Usage

1. Place the lamp on a dry, level surface.
2. Turn the Lamp Head (2) to the desired position.
3. Tap the Touch Button (1) to operate the lamp:
  - Tap once: warm white light
  - Tap again: universal white light (Daylight)
  - Tap again: cool white light
  - Tap again: Off. Status Indicator (8) will be on for 2 seconds to indicate the battery level remaining.
4. To set the brightness, press and hold the Touch Button (1) while the lamp is on. Release when the desired brightness is reached.
5. To check the battery level, press and hold the Touch Button (1), the Status Indicator (8) will be on for 2 seconds to indicate following state:
 

Green:	>70%;
Blue:	40% - 70%;
Red:	10% - 40%;
Rapid flashing red:	less than 10%, battery needs to be recharged as soon as possible.

### Technical data

Model number:	PL5002
Color temperature:	2800K / 5200K / 6500K
Brightness:	Max. 330 lm
Ra:	>85
Power Input:	DC 5V 1A
Battery Capacity:	LiPo battery 3.7V 5000 mAh
Charging time:	Approx. 8 hours
Operating time:	Approx. 5 hours with one charge, up to 20 hours depending on the brightness level
Power:	5W

### Disposal




Please dispose of packaging materials in an environmentally friendly way and take recyclables to collection facilities.



This product is subject to European Directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE). Do not dispose of the product with built-in battery as normal household waste, but through an authorised waste disposal company in an environmentally friendly way.



## Components



## What's in the Box:

- A) Lamp Head x1
- B) Extension Cable x1
- C) Lamp Post Section x3
- D) Lamp Base x1
- E) USB Cable x1
- F) User Guide (This sheet) x1

USB power adapter (not included) is required for charging.




Check the box contents for completeness and the components for transport damage. Do not use if the product is damaged and contact customer service immediately.

## Need Help?



## 1) Desk Lamp (approx. 16" tall)



## 2) Mini Floor Lamp (approx. 48" tall)

