



ENG

TEMPUS-PUMP-RELAY



TEMPUS-PUMP-RELAY



USER'S GUIDE

INTRODUCTION

The TEMPUS-PUMP-RELAY allows to control the openings and closings of a relay in dry contact from a TEMPUS-AG-CT/MV.

SPECIFICATIONS

DIMENSIONS

Width : 10,8 cm
Length : 10,8 cm
Height : 5,2 cm

INSTALLATION

TEMPUS-AG-CT / MV outlet connection.

An irrigation command coming from an outlet activates the CLOSING of the relay connected to the TEMPUS-PUMP-RELAY.

A stopping irrigation command coming from an outlet activates the OPENING of the TEMPUS-PUMP-RELAY.

FUNCTIONALITIES

The TEMPUS-PUMP-RELAY has 1 relay controlled by a 9V command (pulse).

Environmental conditions use:


- Maximum altitude use : 2000m
- Indoor or outdoor (sheltered) installation
- Maximum temperature use : 50°C
- Relative humidity : 90%

BASIC INSTALLATION

With an irrigation command, the relay contact is closing.



With a stopping irrigation command, the relay contact is opening.



TEMPUS-PUMP-RELAY

TORO.

Technical Assistance
Toro.com.au

| For more information visit thelandscapestore.com.au | (02) 9161 3939 |

©2023 The Toro Company
Toro Australia
53 Howards Road, Beverley, SA, 5009