

**AutoLight won't Turn on.**

Firstly, ensure batteries are correctly inserted. If they are, they may be flat. Replace the batteries. If the light tester will still not turn on, please contact our service department.

**AutoLight won't stay on.**

The lamp only stays illuminated for approx. 3 secs, then a result is shown.

**The light globe is not working.**

Return unit for servicing.

**AutoLight turns itself off during use.**

The batteries may be flat. Replace them.

**My AutoLight briefly flashed an incorrect reading and switched off quicker than normal.**

The batteries in your unit are low and don't have enough charge to power the unit. Please replace BOTH with 9 volt batteries.

**How long does a battery last?**

Many hundreds of Tests.

**Can I use a rechargeable battery?**

No. Rechargeable batteries have lower voltage and are not suitable.

**How often do I need to calibrate my AutoLight Tester?**

Every 12 months.

**How long does it take to calibrate my AutoLight?**

It may take one business day to calibrate (Excluding shipping and any repairs).

**Where do I send my AutoLight for calibration?**

Send it to AutoTest Products (see contacts) or your local distributor.

**What should I send when my AutoLight needs service and calibration?**

Please send the device, a business card and updated contact details.

**How long does warranty last?**

12 months parts and labour. 3 months parts and labour for repairs.

**Can I get a longer cord?**

Yes. A longer cord can be purchased as an optional extra, which is double in length. The unit must be recalibrated after the modification.