## **Hinged Branch Repair and Replacement Instructions**

Package will include branch or branches, and accompanying number of pins (Figures 1 and 2).

- 1. Place the branch into the appropriate gap of the tree bracket with hook loop facing up. Line up the hook loop with the holes in the bracket and insert the pin (Figures 3 to 5).
- 2. Secure the pin in place by crimping the inserted side enough so that pin remains loose but will not fall out (Figures 6 to 8).

















