

# WUSIC

**Bluetooth Shower Speaker**

## **USER GUIDE WUSIC-102B**



## REGISTER YOUR DEVICE

Want to win FREE Products from Wusic?

You'll also get an Extended Warranty of 90 Days,  
VIP Pre-Release Product Testing Opportunities  
and Discounts on Reorders!

Register your speaker at  
[www.WusicTech.com/pages/wusic-102b](http://www.WusicTech.com/pages/wusic-102b)

## QUICK START GUIDE



Turn the speaker On/Off/Pairing



Play or Pause Current Song



Short Press – Next Track

Long Press – Increase Volume



Short Press – Previous Track

Long Press – Decrease Volume



Answers or Ends Phone Call



## CHARGING INSTRUCTIONS

This Bluetooth Speaker is powered by an integrated rechargeable lithium battery.

Charge the battery fully before first use.

To charge the battery please:

- ✓ Insert the charging cable (included) into the 5 volt DC socket on the side of the speaker.
- ✓ Connect the other end of the cable into a Computer USB Port or an AC/DC adapter.
- ✓ The red LED under the power button will light, indicating that the battery is charging.
- ✓ When the battery is fully charged, the red LED indicator will turn off.

## TURNING ON AND OFF

**ON** - Press and hold the  button until you hear "Wusic is now ON" and the LED flashes.

**OFF** - Press and hold the  button until you hear "Wusic is turning OFF, Goodbye".

## PAIRING THE SPEAKER TO YOUR BLUETOOTH DEVICE

To pair the speaker to your device please:

- ✓ Turn on the speaker. The speaker automatically goes into the pairing mode.
- ✓ Access the Bluetooth settings on your device. Turn on Bluetooth if it is off.
- ✓ You may have to select scan to have your device re-scan for any Bluetooth devices.
- ✓ Select the device listed as WUSIC-102B from the list of detected devices.
- ✓ If you are asked to input a password please enter "0000". Most devices won't ask.
- ✓ You will hear "Wusic is now Paired" and the LED flashes when the device is connected.
- ✓ Need extra help? For a short video go to [www.WusicTech.com/pages/quick-start](http://www.WusicTech.com/pages/quick-start).

## LISTENING TO YOUR SPEAKER

To use your speaker with your device:

- ✓ On your device, start playing the music. You should hear the music through your speaker.
- ✓ Use the  button to pause the music or to resume playing the music.
- ✓ Use a short press of the  button to advance to the next track.
- ✓ Use a short press of the  button to go to the previous track.
- ✓ Use a long press of the  button to increase the volume.
- ✓ Use a long press of the  button to decrease the volume.
- ✓ By turning off the speaker after each use, it will help to preserve battery life.

To use your speaker with your cell phone:

- ✓ Incoming calls are indicated by a pause in the music and your phones ring tone coming from the speaker. Depending on your cell phone settings you may hear both ringing.
- ✓ Press the  button to answer or end a phone call from the speaker
- ✓ To redial the previous phone call, simply press the  button for 3 seconds.
- ✓ Music will resume after the call ends.

## TROUBLESHOOTING YOUR SPEAKER

Speaker is not turning ON:

- ✓ The battery is most likely not charged fully.
- ✓ Please charge the battery fully.

Speaker can't seem to be paired:

- ✓ The speaker may be on but may no longer be in pairing mode.
- ✓ Please turn off the speaker and then turn it back on again. This will initiate the pairing mode.
- ✓ Please make sure your devices Bluetooth mode is turned on.
- ✓ Please make sure your device is "scanning" for new Bluetooth devices shortly after turning on the speaker.
- ✓ Once a Bluetooth device has been successfully paired with the speaker, it will automatically reconnect the next time you use it as long as the speaker is on and the devices Bluetooth is also turned on.
- ✓ The only exception to this is if your device is not set to remember previous connections, or if that previous connections settings has been deleted from the device.

## USING THE SPEAKER SAFELY

Read this user guide carefully before using the speaker. Please also keep the user guide for future reference should you ever need it.

- ✓ Keep the speaker away from excessive heat, fire, direct sunlight or sharp objects.
- ✓ Do not insert any metal objects inside the speaker to avoid a possible short circuit.
- ✓ Avoid using the speaker in extremely dry environments to avoid a static charge.
- ✓ The speaker is designed for IPx4 level of water splashing. It is not designed to be submerged in the water. Doing so may cause the speaker to malfunction.
- ✓ Do not attempt to open the speaker. Doing so will void any warranties.
- ✓ Please contact Wusic Customer Service at [www.WusicTech.com](http://www.WusicTech.com) for assistance if necessary.

***Thank you for choosing to purchase the Wusic Shower Speaker. We hope that you will enjoy it very much. Please reach out to us and let us know how well we did. We strive to achieve 100% customer satisfaction and hope that we've done that for you.***

## SPECIFICATIONS

Bluetooth version used:	3.0+EDR
Bluetooth signal range:	33 feet (10 meters)
Transmitting frequency:	2.4G Hz
Power supply:	DC5V/100-120mA
Internal battery:	3.7V 400mAh Lithium
Charging time:	Approx. 3 hours
Operating time:	Approx. 6 hours
IP grade:	IPx4
Unit weight:	Approx. 3.5 oz (0.1 kg)

For additional information or to contact customer service please go to our website at [www.WusicTech.com](http://www.WusicTech.com)



Made in China