

W WACACO nanopresso

NS ADAPTER

INSTRUCTIONS







2

Place the NS capsule holder.

Place compatible capsule.





Screw in the NS portafilter.




Add hot water as instructed in Nanopresso user guide and start pumping.

CLEANING



It's important to respect your machine and clean it regularly. A good maintenance will allow you to use your Nanopresso for many years. After each use clean the parts under running water. Let them dry separately.











Sharp cutter inside, only use the provided brush to clean the cutter

and the surrounding area.

Do not put any Nanopresso parts into dishwasher.

INTENDED USE



The NS Adapter accessory is only compatible with the Nanopresso. The NS Adapter is intended to a personal use. It is not suitable for commercial, professional, collective or industrial use.

Use of the NS Adapter in any manner other than as directed herein could cause harm to persons and void the warranty. Wacaco Company Limited will not be responsible for injury or damage resulting from improper use of the NS Adapter.

WARRANTY

Wacaco Company Limited warrants the NS Adapter against defects that are due to faulty materials or workmanship for a period of 12 months from the date of purchase. This warranty is not transferable and does not entitle to compensation in cash. Wacaco Company



Limited disclaims all responsibility for incidental or consequential damages caused by use of this appliance.

This warranty does not cover :

Damage resulting from improper use, abuse, neglect, commercial use or any other use of this appliance not found in this printed manual. Damage of an aesthetic nature, damage due to corrosion or gradual deterioration.

Any disassembly or repairs done by unauthorized persons will void the warranty.

For any repair or exchange, the cost of return is at your expense. If your NS Adapter fails within one year, please contact your Wacaco local distributor or support@wacaco.com directly for repair or exchange.



+91 8951762564 / +91 7411722160 | support@somethingsbrewing.in

3302 L, 12th A Main, HAL 2nd Stage Extention, Indiranagar, Bengaluru, Karnataka 560008