

NXCFRD Radiation Damper Instructions

- 1. Make electrical connections per fan instructions.
- 2. Install motor plate onto the housing.
- 3. Locate the housing on top of the damper as shown and secure with the (4) screws provided. The housing can be installed in one of two positions on the damper: as shown, or rotated 180°.
- 4. Install the radiation damper per local code requirements. Note: The opening edge of the damper should be flush or slightly above the ceiling surface.
- 5. Install the grille and grille springs provided with the radiation damper using tabs shown for the grille springs.

Ventamatic, Ltd. • P.O. Box 728, Mineral Wells, TX 76068 • PH: 1-800-433-1626 • FAX: 940-325-9311