


MANUAL

MONITUM WARNING LIGHT BAR LED

RED = +VDC


BLACK = - TO CHASSIS GROUND

WHITE = CRUISE LIGHT (IF YOU DON'T USE THE WIRELESS REMOTE CONTROL)



PATTERN	PATTERN DESCRIPTION	FLASH RATE (ms)
1	Single flash	480
2	Single flash	480
3	Single flash	232
4	Middle treble flash+left and right treble flash	2100
5	Treble flash	790
6	Combination flash	2588
7	Single flash+penta lash	1824
8	Middle treble flash+left and right treble flash+all treble flash	2200
9	Half and half flash	460
10	Half and half treble flash	480

FOR CRUISE LIGHT

While warning light is on, press  button, and Monitum light bar will switch to cruise light.

Part no. 850139, 850140, 850141, 850142, 850143, 850144, 850145

Contact us if you need support: support@strands.se or +46(0)320-450450



www.strands.se
www.strandseurope.com