



THE ANCHOR WATCH

User Manual



INSIDE THE BOX

- The Anchor Watch

The USN insignia is engraved on the strap hook and the back casing of the watch along with the quote.



*The Anchor Watch was forged from the standards set forth
from the spirit of the Chief Petty Officer.*

DIMENSIONS



TECHNICAL SPECS

CASING

316L Stainless Steel

MOVEMENT

Japanese Miyota 2315

*This is a Quartz movement
- battery operated.*

WATER RESISTANCE

10ATM / 330ft



CHANGING DATE/TIME



SETTING THE DATE

1. Pull the crown out to **Position 1**
2. Turn the crown counter-clockwise to set the date
3. After the date has been set, push the crown back to Default Position

If the date is set between the hours of around 9:00 PM and 1:00 AM, the date may not change the following day.

SETTING THE TIME

1. Pull the crown out to **Position 2**
2. Turn the crown to set hour and minute hands
3. When the crown is pushed back to the Default Position, second hand begins to run

BATTERY

1.5V Button Coin Battery

To change the battery, rotate the back casing using pliers, remove the old battery and replace with a new one in the same location. Secure the casing after the change.



WARRANTY

1 YEAR REPLACEMENT GUARANTEE

When you purchase from our official website:
tenacitywatches.com



Your watch is covered by a 1-year warranty. If you face any issue with your watch, contact us and share a picture along with the details of the issue you're facing and we promise to either help you resolve the issue or exchange with a brand new watch.

We're just a message away. Please connect with us on social media or send us an email if you have any questions.



facebook.com/tenacitywatches



support@tenacitywatches.com



instagram.com/tenacitywatches



TENACITY

PEOPLE OF EXCELLENCE DESERVE EXCELLENCE