




80 Sewing Patterns



Sew Comfortably!



The needle threader easily threads the needle and allows you to start sewing quickly.

Start/Stop Button



[Green]
Ready to start or while sewing

[Red]
Not ready to start

The color of the Start / Stop button indicates the status of the machine.



In bobbin winding condition

Reverse Stitch, Reinforcement Stitch



HZL-H series can sew a lock stitch at the beginning and end of sewing. There are two types of lock stitch, reverse stitch and reinforcement stitch.

Direct Pattern Selection



There are 6 types of stitch patterns, from which you can choose one by directly pushing the pattern button.

Sew Firm!

Needle Up/Down Position Button



Press the button to change up/down position of needle instantly. Also you can change needle stop position and can even sew a half stitch.

Buttonhole



HZL-H series sews the buttonhole automatically according to the size of the button.


Presser Foot Pressure



When sewing thin or thick fabrics, you can get comfortable feed.

Easy to Use!

The Current Setting is Very Visible



Quick Reference Plate



HZL-70HW-A

SPECIFICATIONS

Sewing Speed: Max. 800sti/min

Needle: HA×1 #9~#18

Dimensions: 400(W)×290(H)×188(D)mm

Weight (machine only): 5.8kg

Accessories



A:Standard Presser Foot B:Zipper Foot C:Decorate Stitch Foot D:Overcasting Foot E:Blind Stitch Foot F:Button Sewing Foot G:Buttonhole Foot H:Seam Ripper/ Brush I:Screwdriver (S) J:Screwdriver (L-shape) K:Auxilliary Spool Pin L:Bobbin (3x) M:Quilt Guide N:Spool Cap(Large) O:Spool Cap(Small) P:Spool Pin Felt Q:Pack of Needles(3x)







Foot Controller

Other Features

- Free Arm
- Drop-in Bobbin
- Drop Feed
- Easy to Start Sewing Thick Fabrics
- Button Sewing



JUKI CORPORATION

2-11-1, TSURUMAKI, TAMA-SHI, TOKYO 206-8551, JAPAN http://www.juki.co.jp

