






NO.	ICEBEAR PARTS NO.	Chinese name	Description	QTY
1	PMZ125-1-A-001	前泥板	front fender	1
2	PMZ125-1-A-002	车架挡泥板右	frame fender RH	1
3	PMZ125-1-A-003	车架挡泥板左	frame fender LH	1
4	PMZ125-1-A-004	右面板装饰件	FACE COVER ORNEMENT, RH	1
5	PMZ125-1-A-005	左面板装饰件	FACE COVER ORNEMENT, LH	1
6	PMZ125-1-A-006	右装饰罩	ORNEMENT COVER RH	1
7	PMZ125-1-A-007	左装饰罩	ORNEMENT COVER LH	1
8	PMZ125-1-A-008	右前面板	FRONT FACE COVER RH	1
9	PMZ125-1-A-009	左前面板	FRONT FACE COVER LH	1
10	PMZ125-1-A-010	后右边条	REAR PLATE RH	1
11	PMZ125-1-A-011	后左边条	REAR PLATE LH	1
12	PMZ125-1-A-012	后边条	REAR PLATE	1



NO.	ICEBEAR PARTS NO.	Chinese name	Description	QTY
1	PMZ125-1-B-001	右内测板	INNER SIDE COVER RH	1
2	PMZ125-1-B-002	左内测板	INNER SIDE COVER LH	1
3	PMZ125-1-B-003	油箱盖板	FUEL TANK COVER	1
4	PMZ125-1-B-004	内测板	INNER SIDE COVER	1
5	PMZ125-1-B-005	后泥板	REAR FENDER	1
6	PMZ125-1-B-006	内泥板	INNER FENDER	1




NO.	ICEBEAR PARTS NO.	Chinese name	Description	QTY
1	PMZ125-1-C-001	座垫	seat	1
2	PMZ125-1-C-002	套锁	ignition assy	1
3	PMZ125-1-C-003	座垫锁	seat lock	1
4	PMZ125-1-C-004	座垫拉线	seat cable	1




NO.	ICEBEAR PARTS NO.	Chinese name	Description	QTY
1	PMZ125-1-D-001	发动机	ENGINE	1
2	PMZ125-1-D-002	导线	MAIN WIRES	1
3	PMZ125-1-D-003	进气管纸垫	INTAKE PIPE WASHER	1
4	PMZ125-1-D-004	进气管橡胶垫	INTAKE PIPE RUBBER WASHER	1
5	PMZ125-1-D-005	进气管	INTAKE PIPE	1
6	PMZ125-1-D-006	化油器	CARBURETOR	1
7	PMZ125-1-D-007	闪光器	RELAY ASSY, TUN SIGNAL	1

8	PMZ125-1-D-008	起动继电器	STARTER RELAY	1
9	PMZ125-1-D-009	高压泵	IGNITION COIL	1
10	PMZ125-1-D-010	点火器	CDI	1
11	PMZ125-1-D-011	稳压器	REGULATOR	1
12	PMZ125-1-D-012	喇叭	HORN	1
13	PMZ125-1-D-013	转速感应线	SPEEDO CABLE	1
14	PMZ125-1-D-014	发动机轴1	ENGINE AXLE 1	1
15	PMZ125-1-D-015	发动机轴2	ENGINE AXLE 2	1




NO.	ICEBEAR PARTS NO.	Chinese name	Description	QTY
1	PMZ125-1-E-001	前减	FRONT SHOCK	1
2	PMZ125-1-E-002	前碟刹	FRONT BRAKE	1
3	PMZ125-1-E-003	上联板	STEERING HEAD	1
4	PMZ125-1-E-004	下联板	STEERING STEM	1


5	PMZ125-1-E-005	钢圈	STEEL BOWEL	1
---	----------------	----	-------------	---




NO.	ICEBEAR PARTS NO.	Chinese name	Description	QTY
1	PMZ125-1-F-001	方向把	HANDLEBAR	1
2	PMZ125-1-F-002	离合器手柄	CLUTCH GRIP	1
3	PMZ125-1-F-003	右开关	RIGHT CONTROL PANEL	1
4	PMZ125-1-F-004	右胶套	HAND GRIP (RIGHT)	1
5	PMZ125-1-F-005	左胶套	HAND GRIP (LEFT)	1
6	PMZ125-1-F-006	左开关	LEFT CONTROL PANEL	1
7	PMZ125-1-F-007	缓冲皮	RUBBER WASHER	1
8	PMZ125-1-F-008	把手座	HANDLEBAR HOLDER	1
9	PMZ125-1-F-009	把手压块	HANDLEBAR HOLDER	1




NO.	ICEBEAR PARTS NO.	Chinese name	Description	QTY
1	PMZ125-1-G-001	右脚蹬组件	FOOT RESTER RH	1
2	PMZ125-1-G-002	左脚蹬组件	FOOT RESTER LH	1
3	PMZ125-1-G-003	单撑	KICK STAND	1
4	PMZ125-1-G-004	刹车踏杆	BRAKE PEDAL LEVER	1
5	PMZ125-1-G-005	变档杆	GEAR SHIFTER	1
6	PMZ125-1-G-006	后碟刹	REAR BRAKE	1




NO.	ICEBEAR PARTS NO.	Chinese name	Description	QTY
1	PMZ125-1-H-001	消音器筒子	MUFFER	1
2	PMZ125-1-H-002	消音器弯管	EXHAUST	1
3	PMZ125-1-H-003	大灯支架	BRACKET HEAD LIGHT	1
4	PMZ125-1-H-004	后尾灯支架	BRACKET TAIL LIGHT	1
5	PMZ125-1-H-005	空滤器	AIR FILTER	1



NO.	ICEBEAR PARTS NO.	Chinese name	Description	QTY
1	PMZ125-1-I-001	后平叉衬套	REAR BUSHING	1
2	PMZ125-1-I-002	后平叉	SWING ARM	1
3	PMZ125-1-I-003	后减	REAR SHOCK	1
4	PMZ125-1-I-004	链条调节器	CHAIN ADJUSTER	1




NO.	ICEBEAR PARTS NO.	Chinese name	Description	QTY
1	PMZ125-1-J-001	车架	FRAME	1
2	PMZ125-1-J-002	支架1	BRACKET 1	1
3	PMZ125-1-J-003	支架2	BRACKET 2	1
4	PMZ125-1-J-004	支架3	BRACKET 3	1




NO.	ICEBEAR PARTS NO.	Chinese name	Description	QTY
1	PMZ125-1-K-001	油箱	FUEL TANK	1
2	PMZ125-1-K-002	油箱缓冲块	FUEL TANK RUBBER WASHER	1
3	PMZ125-1-K-003	后视镜	REAR MIRROR	1
4	PMZ125-1-K-004	油位传感器	GAS SENSOR	1
5	PMZ125-1-K-005	蓄电池	BUTTERY	1
6	PMZ125-1-K-006	离合线	CLUTCH CABLE	1
7	PMZ125-1-K-007	座垫拉线	SEAT CABLE	1
8	PMZ125-1-K-008	转速器	SPEED SENSER	1
9	PMZ125-1-K-009	油门线	Throttle cable	1





NO.	ICEBEAR PARTS NO.	Chinese name	Description	QTY
1	PMZ125-1-L-001	后轮胎	REAR TIRE	1
2	PMZ125-1-L-002	后钢圈	REAR RIM	1
3	PMZ125-1-L-003	后碟刹盘	REAR BRAKE DISC	1
4	PMZ125-1-L-004	链轮座	SPROCKET HOLDER	1
5	PMZ125-1-L-005	链轮	SPROCKET	1
6	PMZ125-1-L-006	链轮缓冲块	SPROCKET RUBBER WASHER	1
7	PMZ125-1-L-007	后轮轴	AXLE	1
8	PMZ125-1-L-008	螺母	NUT	1
9	PMZ125-1-L-009	衬套	BUSHING	1



NO.	ICEBEAR PARTS NO.	Chinese name	Description	QTY
1	PMZ125-1-M-001	前轮胎	FRONT TIRE	1
2	PMZ125-1-M-002	前钢圈	FRONT RIM	1
3	PMZ125-1-M-003	前碟刹盘	FRONT BRAKE DISC	1
4	PMZ125-1-M-004	前轮轴	FRONT AXLE	1
5	PMZ125-1-M-005	衬套	BUSHING	1
6	PMZ125-1-M-006	螺母	NUT	1



NO.	ICEBEAR PARTS NO.	Chinese name	Description	QTY
1	PMZ125-1-N-001	大灯	HEADLIGHT	1
2	PMZ125-1-N-002	尾灯	REAR LIGHT	1
3	PMZ125-1-N-003	仪表	SPEEDOMETER	1
4	PMZ125-1-N-004	后转向灯	REAR TURN LIGHT	1