



序号 SR	件号Part No.	名称Description	名称Description	数量Qty
1	PMZ150-11-A-001	Front tire	前轮胎	1
2	PMZ150-11-A-002	Front rim	前轮毂	1
3	PMZ150-11-A-003	Front disc brake	前碟刹	1
4	PMZ150-11-A-004	Steering stem	下联板	1
5	PMZ150-11-A-005	Front Shock LH, RH	前左右减震	2
6	PMZ150-11-A-006	Front brake disc	前制动盘	1
7	PMZ150-11-A-007	Bowl	钢碗	7
8	PMZ150-11-A-008	Front disc brake clip	前碟刹线夹	1
9	PMZ150-11-A-009	Speed sensor	转速器	1
10	PMZ150-11-A-010	Front axle	前轮轴	1
11	PMZ150-11-A-011	Front wheel bushing	前轮衬套	1
12	PMZ150-11-A-012	Self lock screw	自锁螺母	1
13	PMZ150-11-A-013	Speedo cable clip	里程线线夹	1
14	PMZ150-11-A-014	Tubeless Valve	气门嘴	1



序号 SR	件号Part No.	名称Description	名称Description	数量Qty
1	PMZ150-11-B-001	Left panel	左装饰板	1
2	PMZ150-11-B-002	Right panel	右装饰板	1
3	PMZ150-11-B-003	Seat front cover	座桶前围	1
4	PMZ150-11-B-004	Rear carrier	后货架	1
5	PMZ150-11-B-005	Front cover cap	前围小盖	1
6	PMZ150-11-B-006	Panel accessories front LH	前左装饰板小件	1
7	PMZ150-11-B-007	Panel accessories front RH	前右装饰板小件	1
8	PMZ150-11-B-008	Helmet hook	头盔挂钩	1
9	PMZ150-11-B-009	Seat lock cap	坐垫锁盖板	1
10	PMZ150-11-B-010	Battery	蓄电池	1



序号 SR	件号Part No.	名称Description	名称Description	数量Qty
1	PMZ150-11-C-001	Front panel RH	前左装饰板	1
2	PMZ150-11-C-002	Front panel LH	前右装饰板	1
3	PMZ150-11-C-003	Front cover	前面罩	1
4	PMZ150-11-C-004	Head lamp	前大灯	1
5	PMZ150-11-C-005	Left cover	左边条	1
6	PMZ150-11-C-006	Right cover	右边条	1
7	PMZ150-11-C-007	Ornament cover LH (iron)	左装饰盖 (铁)	1
8	PMZ150-11-C-008	Ornament cover RH (iron)	右装饰盖 (铁)	1
9	PMZ150-11-C-009	Headlight grid, chrome	镀铬大灯网格	1
10	PMZ150-11-C-010	Headlight brim	大灯帽檐	1
11	PMZ150-11-C-011	Front panel grid	前面板网格	1
12	PMZ150-11-C-012	Front edge reflector plate	前边缘反射器	2



序号 SR	件号Part No.	名称Description	名称Description	数量Qty
1	PMZ150-11-D-001	Mud guard	车架挡泥板	1
2	PMZ150-11-D-002	Box	杂物箱	1
3	PMZ150-11-D-003	Seat	坐垫	1
4	PMZ150-11-D-004	Box cap	杂物箱内盖	1



序号 SR	件号Part No.	名称Description	名称Description	数量Qty
1	PMZ150-11-E-001	Tool box	工具箱	1

2	PMZ150-11-E-002	Foot rest	脚踏板	1
3	PMZ150-11-E-003	Tool box cap	工具箱盖	1
4	PMZ150-11-E-004	Battery cap	电瓶盖	1
5	PMZ150-11-E-005	VIN cover	号码盖	1
6	PMZ150-11-E-006	Foot pedal supporting	脚踏板撑板	1



序号 SR	件号Part No.	名称Description	名称Description	数量Qty
1	PMZ150-11-F-001	Engine	发动机	1
2	PMZ150-11-F-002	Rear fender	后轮挡泥板	1
3	PMZ150-11-F-003	Rear rim	后轮毂	1
4	PMZ150-11-F-004	Rear tire	后轮胎	1
5	PMZ150-11-F-005	Muffler	消音器	1
6	PMZ150-11-F-006	Engine connect plate	动力连接板	1
7	PMZ150-11-F-007	Air filter	空滤器	1
8	PMZ150-11-F-008	Carburetor	化油器	1
9	PMZ150-11-F-009	Rear Shock	后减震	2
10	PMZ150-11-F-010	Fender bracket, rear, big	后挡泥板支架大	1
11	PMZ150-11-F-011	Fender bracket, rear, small	后挡泥板支架小	1
12	PMZ150-11-F-012	Tubeless Valve	气门嘴	1
13	PMZ150-11-F-013	Engine axle	发动机轴	1



序号 SR	件号Part No.	名称Description	名称Description	数量Qty
1	PMZ150-11-G-001	Upper rear fender	后挡泥板上部	1
2	PMZ150-11-G-002	Lower rear fender	后挡泥板下部	1
3	PMZ150-11-G-003	Rear winker LH	后转向灯左	1
4	PMZ150-11-G-004	Rear winker RH	后转向灯右	1
5	PMZ150-11-G-005	Tail lamp	后尾灯	1
6	PMZ150-11-G-006	License holder	牌照支架	1
7	PMZ150-11-G-007	Rear reflector plate	后反射镜片	1
8	PMZ150-11-G-008	Rear edge reflector plate	后边缘反射器	2




序号 SR	件号Part No.	名称Description	名称Description	数量Qty
1	PMZ150-11-H-001	Trunk	尾箱	1
2	PMZ150-11-H-002	Trunk holder	尾箱底板	1
3	PMZ150-11-H-003	Front fender	前轮挡泥板	1

4	PMZ150-11-H-004	Tail box cushion	尾箱垫皮	1
5	PMZ150-11-H-005	Tail box fixing strap	尾箱固定带	1




序号 SR	件号Part No.	名称Description	名称Description	数量Qty
1	PMZ150-11-I-001	Windshield	挡风罩	1
2	PMZ150-11-I-002	Left handle cover	左把手护罩	1
3	PMZ150-11-I-003	Right handle cover	右把手护罩	1
4	PMZ150-11-I-004	Rear mirror LH	后视镜左	1
5	PMZ150-11-I-005	Rear mirror RH	后视镜右	1
6	PMZ150-11-I-006	front winker LH	前转向灯左	1
7	PMZ150-11-I-007	front winker RH	前转向灯右	1
8	PMZ150-11-I-008	Front light	前照灯	1
9	PMZ150-11-I-009	Windshield cover	挡风罩小盖	1
10	PMZ150-11-I-010	Handle bar	方向把手	1
11	PMZ150-11-I-011	Left switch	左开关	1
12	PMZ150-11-I-012	Right switch	右开关	1
13	PMZ150-11-I-013	Left grip	左把手套	1
14	PMZ150-11-I-014	Throttle grip	油门把手套	1
15	PMZ150-11-I-015	Rear disc brake	后刹线	1
16	PMZ150-11-I-016	speedo shell	仪表壳	1
17	PMZ150-11-I-017	speedo cable	里程线	1
18	PMZ150-11-I-018	Throttle cable	油门线	1
19	PMZ150-11-I-019	Speedo	仪表	1



序号 SR	件号Part No.	名称Description	名称Description	数量Qty
1	PMZ150-11-J-001	Fuel tank	油箱	1
2	PMZ150-11-J-002	harness	电缆	1
3	PMZ150-11-J-003	fuel sensor	油位传感器	1
4	PMZ150-11-J-004	fuel tank cap	油箱盖	1
5	PMZ150-11-J-005	Seal rubber	密封橡胶圈	1
6	PMZ150-11-J-006	Sensor plate	传感器压板	1
7	PMZ150-11-J-007	Fuel tank switch	油箱开关	1
8	PMZ150-11-J-008	CDI	点火器	1
9	PMZ150-11-J-009	Horn	喇叭	1
10	PMZ150-11-J-010	Regulator	稳压器	1
11	PMZ150-11-J-011	Ignition coil	高压包	1
12	PMZ150-11-J-012	Starter relay	启动继电器	1
13	PMZ150-11-J-013	Flasher	闪光器	1
14	PMZ150-11-J-014	Key set	套锁	1
15	PMZ150-11-J-015	Seat lock holder	坐垫锁支架	1
16	PMZ150-11-J-016	Bracket	面板支架	1
17	PMZ150-11-J-017	Seat cushion pull	坐垫拉线	1
18	PMZ150-11-J-018	Hose	油管	3
19	PMZ150-11-J-019	Step bracket	脚蹬支架	2
20	PMZ150-11-J-020	Rear step	后脚蹬	2





序号 SR NO	件号Part No.	名称Description	名称Description	数量Qty
1	PMZ150-3C-K-001	Frame	车架	1
2	PMZ150-3C-K-002	Hangger	吊架	1
3	PMZ150-3C-K-003	Main stand	双撑	1
4	PMZ150-3C-K-004	Main stand spring	双撑弹簧	1
5	PMZ150-3C-K-005	Kick stand spring	单撑弹簧	1
6	PMZ150-3C-K-006	Kick stand	单撑	1