




| NO. | ICEBEAR PARTS NO. | Description | Chinese name | QTY |
|-----|-------------------|-------------------|--------------|-----|
| 1 | PMZ150-19-A-1 | frame | 车架 | 1 |
| 2 | PMZ150-19-A-2 | nut | M10自锁螺母 | 1 |
| 3 | PMZ150-19-A-3 | axle | 发动机轴10*238 | 1 |
| 4 | PMZ150-19-A-4 | hangger | 吊架 | 1 |
| 5 | PMZ150-19-A-5 | bolt | 螺栓10*60 | 2 |
| 6 | PMZ150-19-A-6 | nut | M10自锁螺母 | 2 |
| 7 | PMZ150-19-A-7 | bushing | 衬套 | 1 |
| 8 | PMZ150-19-A-8 | spring | 弹簧 | 2 |
| 9 | PMZ150-19-A-9 | front footpeg pin | 前脚蹬销子 | 2 |


| | | | | |
|----|----------------|-----------------|--------------------|---|
| 10 | PMZ150-19-A-10 | pin | 开口销 | 2 |
| 11 | PMZ150-19-A-11 | front footpeg | 前脚踏 | 2 |
| 12 | PMZ150-19-A-12 | bolt | 电池盒螺栓 (6*12, 6*16) | 3 |
| 13 | PMZ150-19-A-13 | HOLDER, BATTERY | 电池盒 | 1 |




| NO. | ICEBEAR PARTS NO. | Description | Chinese name | QTY |
|-----|-------------------|----------------------------|--------------|-----|
| 1 | PMZ150-19-B-1 | enngine | 发动机 | 1 |
| 2 | PMZ150-19-B-2 | connecting plate | 动力连接板 | 1 |
| 3 | PMZ150-19-B-3 | CARBURETOR | 化油器 | 1 |
| 4 | PMZ150-19-B-4 | Rear Brake Shoe Set | 后制动蹄块 | 2 |
| 5 | PMZ150-19-B-5 | turn Spring, Rear Brake Sh | 蹄块弹簧 | 2 |
| 6 | PMZ150-19-B-6 | bear | 轴承 | 2 |
| 7 | PMZ150-19-B-7 | oil seal | 油封 | 2 |
| 8 | PMZ150-19-B-8 | bush | 缓冲衬套 | 1 |
| 9 | PMZ150-19-B-9 | clip | 卡簧 | 2 |



| NO. | ICEBEAR PARTS NO. | Description | Chinese name | QTY |
|-----|-------------------|-------------|--------------|-----|
| 1 | PMZ150-19-C-1 | rear tire | 后轮胎 | 1 |
| 2 | PMZ150-19-C-2 | rear rim | 后钢圈 | 1 |
| 3 | PMZ150-19-C-3 | rear hub | 轮毂芯 | 1 |
| 4 | PMZ150-19-C-4 | nut | 轮胎螺母 | 4 |
| 5 | PMZ150-19-C-5 | bolt | 六角螺栓10*40 | 4 |



| NO. | ICEBEAR PARTS NO. | Description | Chinese name | QTY |
|-----|-------------------|----------------------------|--------------|-----|
| 1 | PMZ150-19-D-1 | bracket, headlight | 大灯支架 | 1 |
| 2 | PMZ150-19-D-2 | headlight cover | 大灯罩 | 1 |
| 3 | PMZ150-19-D-3 | front shield install frame | 前罩安装支架 | 1 |
| 4 | PMZ150-19-D-4 | bolt | 大头螺栓6*12 | 3 |
| 5 | PMZ150-19-D-5 | rubber pad | 橡胶垫圈 | 3 |
| 6 | PMZ150-19-D-6 | bolt | 法兰边螺栓8*16 | 2 |
| 7 | PMZ150-19-D-7 | front turning | 前左右转向灯 | 2 |
| 8 | PMZ150-19-D-8 | Bulb, Headlight | 大灯 | 2 |




| NO. | ICEBEAR PARTS NO. | Description | Chinese name | QTY |
|-----|-------------------|-------------------|--------------|-----|
| 1 | PMZ150-19-E-1 | bolt | 单撑螺栓10*25 | 1 |
| 2 | PMZ150-19-E-2 | kick stand spring | 单撑弹簧 | 1 |
| 3 | PMZ150-19-E-3 | kick stand | 单撑 | 1 |



| NO. | ICEBEAR PARTS NO. | Description | Chinese name | QTY |
|-----|-------------------|---------------------|--------------|-----|
| 1 | PMZ150-19-F-1 | LATTER GUARD SHIELD | 前罩 | 1 |
| 2 | PMZ150-19-F-2 | rear shield | 后罩 | 1 |
| 3 | PMZ150-19-F-3 | bolt | 自攻螺栓4.8*16 | 8 |
| 4 | PMZ150-19-F-4 | nut | 装饰扣 | 8 |




| NO. | ICEBEAR PARTS NO. | Description | Chinese name | QTY |
|-----|-------------------|---------------------|--------------|-----|
| 1 | PMZ150-19-G-1 | front fender | 前泥板 | 1 |
| 2 | PMZ150-19-G-2 | bolt | 法兰边螺栓6*16 | 3 |
| 3 | PMZ150-19-G-3 | nut | M6防滑螺母 | 1 |
| 4 | PMZ150-19-G-4 | front shock (left) | 左前减震 | 1 |
| 5 | PMZ150-19-G-5 | front shock (right) | 右前减震 | 1 |
| 6 | PMZ150-19-G-6 | connecting plate | 连接板 | 1 |
| 7 | PMZ150-19-G-7 | bolt | 法兰边螺栓10*30 | 4 |
| 8 | PMZ150-19-G-8 | steering stem | 下联板 | 1 |
| 9 | PMZ150-19-G-9 | bearing | 钢碗 | 1 |
| 10 | PMZ150-19-G-10 | steering stem cover | 下联板罩 | 1 |
| 11 | PMZ150-19-G-11 | bolt | 内六角螺栓6*20 | 2 |



| NO. | ICEBEAR PARTS NO. | Description | Chinese name | QTY |
|-----|-------------------|-------------|--------------|-----|
| 1 | PMZ150-19-H-1 | handlebar | 把手 | 1 |

| | | | | |
|----|----------------|--------------------------|-----------|---|
| 2 | PMZ150-19-H-2 | LEFT COMBINATION SWITCH | 左开关 | 1 |
| 3 | PMZ150-19-H-3 | right COMBINATION SWITCH | 右开关 | 1 |
| 4 | PMZ150-19-H-4 | GRIP | 左胶套 | 1 |
| 5 | PMZ150-19-H-5 | THROTTLE GRIP | 油门胶套 | 1 |
| 6 | PMZ150-19-H-6 | handle guide | 把手座 | 1 |
| 7 | PMZ150-19-H-7 | handlebar lock | 把手压块 | 2 |
| 8 | PMZ150-19-H-8 | nut | M10自锁螺母 | 1 |
| 9 | PMZ150-19-H-9 | SPRING WASHER | M10弹簧垫 | 1 |
| 10 | PMZ150-19-H-10 | bushing | 把手衬套 | 1 |
| 11 | PMZ150-19-H-11 | bolt | 六角螺栓10*50 | 1 |
| 12 | PMZ150-19-H-12 | speedometer | 仪表 | 1 |
| 13 | PMZ150-19-H-13 | bolt | 法兰边螺栓6*16 | 2 |
| 14 | PMZ150-19-H-14 | rear mirror | 后视镜 | 2 |




| NO. | ICEBEAR PARTS NO. | Description | Chinese name | QTY |
|-----|-------------------|------------------------|--------------|-----|
| 1 | PMZ150-19-I-1 | MAIN WIRE | 导线总成 | 1 |
| 2 | PMZ150-19-I-2 | HORN | 喇叭 | 1 |
| 3 | PMZ150-19-I-3 | STARTER RELAY | 启动继电器 | 1 |
| 4 | PMZ150-19-I-4 | CDI | 点火器 | 1 |
| 5 | PMZ150-19-I-5 | REGULATOR | 稳压器 | 1 |
| 6 | PMZ150-19-I-6 | SWITCH ASSY, IGNITION | 电锁 | 1 |
| 7 | PMZ150-19-I-7 | IGNITION COIL | 高压泵 | 1 |
| 8 | PMZ150-19-I-8 | RELAY ASSY, TUN SIGNAL | 闪光器 | 1 |




| NO. | ICEBEAR PARTS NO. | Description | Chinese name | QTY |
|-----|-------------------|------------------|--------------|-----|
| 1 | PMZ150-19-J-1 | rear brake cable | 后刹线 | 1 |
| 2 | PMZ150-19-J-2 | THROTTLE CABLE | 油门线 | 1 |
| 3 | PMZ150-19-J-3 | speedo cable | 里程线 | 1 |
| 4 | PMZ150-19-J-4 | speed senser | 转速器 | 1 |


| | | | | |
|---|---------------|-------------|----|---|
| 5 | PMZ150-19-J-5 | cable clamp | 线夹 | 1 |
|---|---------------|-------------|----|---|



| NO. | ICEBEAR PARTS NO. | Description | Chinese name | QTY |
|-----|-------------------|-----------------------|--------------|-----|
| 1 | PMZ150-19-K-1 | FUEL TANK COVER | 油箱上护板 | 1 |
| 2 | PMZ150-19-K-2 | FUEL TANK BRACKET | 脚踏支架 | 1 |
| 3 | PMZ150-19-K-3 | COVER UNDER FUEL TANK | 油箱下护板 | 1 |
| 4 | PMZ150-19-K-4 | bolt | 法兰边螺栓6*25 | 4 |
| 5 | PMZ150-19-K-5 | bolt | 法兰边螺栓6*16 | 2 |
| 6 | PMZ150-19-K-6 | SPRING WASHER | M6平垫 | 4 |
| 7 | PMZ150-19-K-7 | bolt | 内六角螺栓6*12 | 4 |
| 8 | PMZ150-19-K-8 | nut | 装饰扣 | 4 |



| NO. | ICEBEAR PARTS NO. | Description | Chinese name | QTY |
|-----|-------------------|------------------|--------------|-----|
| 1 | PMZ150-19-L-1 | cover under seat | 坐垫下护板 | 1 |
| 2 | PMZ150-19-L-2 | oil pump | 油泵 | 1 |
| 3 | PMZ150-19-L-3 | nut | 防滑螺母M6 | 1 |
| 4 | PMZ150-19-L-4 | bushing | 油冷衬套 | 1 |
| 5 | PMZ150-19-L-5 | bolt | 5*20内六角螺栓 | 2 |




| NO. | ICEBEAR PARTS NO. | Description | Chinese name | QTY |
|-----|-------------------|------------------|--------------|-----|
| 1 | PMZ150-19-M-1 | front tire | 前轮胎 | 1 |
| 2 | PMZ150-19-M-2 | front rim | 前轮钢圈 | 1 |
| 3 | PMZ150-19-M-3 | front brake disc | 前刹车盘 | 1 |
| 4 | PMZ150-19-M-4 | bushing | 衬套 | 1 |
| 5 | PMZ150-19-M-5 | nut | M12自锁螺母 | 1 |
| 6 | PMZ150-19-M-6 | front axle | 前轮轴12*210 | 1 |
| 7 | PMZ150-19-M-7 | front brake | 前碟刹 | 1 |
| 7-1 | PMZ150-19-M-8 | Master cylinder | 碟刹上泵 | 1 |
| 7-2 | PMZ150-19-M-9 | brake lever | 碟刹手柄 | 1 |
| 7-3 | PMZ150-19-M-10 | Brake Line | 碟刹油管 | 1 |
| 7-4 | PMZ150-19-M-11 | Brake Caliper | 碟刹下泵 | 1 |
| 7-5 | PMZ150-19-M-12 | Brake Pad | 摩擦片 | 2 |
| 8 | PMZ150-19-M-13 | bracket | 支架 | 1 |
| 9 | PMZ150-19-M-14 | bolt | 法兰边螺栓8*35 | 2 |



| NO. | ICEBEAR PARTS NO. | Description | Chinese name | QTY |
|-----|-------------------|--------------------|--------------|-----|
| 1 | PMZ150-19-N-1 | rear turning light | 后左右转向灯 | 2 |
| 2 | PMZ150-19-N-2 | rear shock | 后减 | 2 |
| 3 | PMZ150-19-N-3 | rear light | 尾灯 | 1 |



| NO. | ICEBEAR PARTS NO. | Description | Chinese name | QTY |
|-----|-------------------|-------------|--------------|-----|
| 1 | PMZ150-19-0-1 | muffer | 消音器筒子 | 1 |
| 2 | PMZ150-19-0-2 | paper pad | 消音器石棉垫 | 1 |
| 3 | PMZ150-19-0-3 | exhaust | 消音器弯管 | 1 |
| 4 | PMZ150-19-0-4 | clip | 抱箍 | 2 |
| 5 | PMZ150-19-0-5 | bolt | 内六角螺栓8*20 | 3 |
| 6 | PMZ150-19-0-6 | bolt | 法兰边螺栓8*25 | 2 |



| NO. | ICEBEAR PARTS NO. | Description | Chinese name | QTY |
|-----|-------------------|-------------|--------------|-----|
| 1 | PMZ150-19-P-1 | fuel tank | 油箱 | 1 |
| 2 | PMZ150-19-P-2 | GAS SENSOR | 油位传感器 | 1 |



| NO. | ICEBEAR PARTS NO. | Description | Chinese name | QTY |
|-----|-------------------|--------------------|--------------|-----|
| 1 | PMZ150-19-Q-1 | seat | 坐垫 | 1 |
| 2 | PMZ150-19-Q-2 | intake manifold | 进气弯管 | 1 |
| 3 | PMZ150-19-Q-3 | air filter | 空滤器 | 1 |
| 4 | PMZ150-19-Q-4 | clamp | 卡箍 | 2 |
| 5 | PMZ150-19-Q-5 | FIXED BUCKLE | 固定扣 | 2 |
| 6 | PMZ150-19-Q-6 | air filter bracket | 空滤支架 | 1 |
| 7 | PMZ150-19-Q-7 | bolt | 十字圆头螺栓5*16 | 2 |
| 8 | PMZ150-19-Q-8 | nut | M5防滑螺母 | 2 |



| NO. | ICEBEAR PARTS NO. | Description | Chinese name | QTY |
|-----|-------------------|-------------|--------------|-----|
| 1 | PMZ150-19-R-1 | tool | 工具 | 1 |
| 2 | PMZ150-19-R-2 | battery | 蓄电池 | 1 |
| 3 | PMZ150-19-R-3 | electrolyte | 电解液 | 1 |
| 4 | PMZ150-19-R-4 | bolt | 电瓶螺栓5*10 | 2 |