


CLOUD NINE®

CLOUD NINE i3 Sonido i3

USER GUIDE

PACKING LIST



- Wireless Earphones x2
- Magnetic Charging Case x1
- USB Charging Cable x1
- Ear Tips x6 pairs
- User Manual x1
- Gift Box x1

1

IMPORTANT NOTES

- Before using CLOUD NINE i3 Wireless earphones, please charge both the case and the earphones;
- While you are trying to connect the earphones to a new device, make sure the earphones are not connected with any other devices;
- We provide 6 pairs of ear tips (including pair installed on the earphones), please select the best fit for your earshape.
- The key to quality sound in any earphone is the FIT of the rubber ear tips to the listener. If you don't have a snug fit, you could lose up to 30%-70% of sound quality.


2

CONNECT FOR STEREO MODE

Follow the tips to connect your earphones:

Step 1: Power on

The earphones will power on AUTOMATICALLY when removed from the charging case with a voice prompt of "POWER ON". (Or you can also press the power keys on both earphones up to 2 seconds to turn them on manually).




3

Step 2: Pairing

When both earphones are on, the left and right earphones will connect with each other AUTOMATICALLY with a voice prompt from each earphone.

Once the two earphones are connected, the right earphone (master device) will enter into the pairing mode AUTOMATICALLY with a voice prompt of "PAIRING".



Step 3: Connected


Search and select "CLOUD NINE i3" on your smart phone to finish your set up, with a voice prompt of "CONNECTED" from the left earphone.



4

Step: Power off

Return the earphones to the charging case or press the power key on either of earphones for up to 8 seconds to turn off the earphones.



Note: If you pick up just one earphone, it will enter mono mode.

If you want to switch to stereo mode, remove the other earphone from the charging case. (Both earphones will need to be connected to the same mobile phone)

5

Controls

AUDIO PLAYING

Touch L/R earphone Play/pause

Double click R earphone Next track

Double click L earphone Previous track

Long press R earphone. When reach the maximum tone, you will hear "Beep". Volume+

Long press L earphone. When reach the minimum tone, you will hear "Beep". Volume-

6

AUDIO PLAYING

Short Press Answer/End call

Long press R/L earphone for 2s Reject call

VOICE ASSISTANT

Triple click L/R Activate Siri/ other voice control software

Note: Please make sure your mobile device supports this function

CHARGING

(1) Charging the Earphones:

The earphones will be charged automatically when you return them to the charging case.

7

AUDIO PLAYING

Short Press Answer/End call

Long press R/L earphone for 2s Reject call

VOICE ASSISTANT

Triple click L/R Activate Siri/ other voice control software

Note: Please make sure your mobile device supports this function

CHARGING


(1) Charging the Earphones:

The earphones will be charged automatically when you return them to the charging case.

8


Earphone status indicator

Steady white	Charging
Off	Fully Charged



(2) Charging the Case:

Use 5V adapter (not included) to charge the case. The white LED indicators will blink while charging. When fully charged the lights will stop blinking.




8

(3) LED Battery Indicator:

Trigger this function by any one of the following actions:
Option 1. Open the cover of the case;
Option 2. Remove the earphones from the case;
Option 3. Return the earphone to the case.

The four LED indicators correspond to different battery levels.



9

SPECIFICATIONS

- Bluetooth Version: V5.0
- Compatible codec: AAC, SBC, APTX
- Profile: A2DP, HFP, HSP, AVRCP
- Weight: Earbuds: 4.4g, Charging case: 29.4g
- Size: Earbud: 20*16.1*15.1mm, Charging case: 60*26*32.8mm
- Speaker driver: 16ohm Φ6
- Bluetooth distance: 10m
- Play time: 7H
- Talk time: 6.5H
- Frequency: 20~20kHz
- Charging time: 1.5h~2h
- Earbuds battery: 50mAh
- Standby time(earphones in the case): 350H
- Charging case battery: 400mAh
- Charging times: 3
- Power: 4dBm
- Frequency: 2402MHz-2480MHz

10

FAQ

- Q: The earphones won't turn on/off automatically.
A: If the battery of the charging case is low, the earphones can NOT power on/off automatically. Please charge the case fully and try again.

- Q: How do I connect the earphones to each other?
A: (1) Remove the left and right earphone from charging case or press the power key for 2 seconds.
(2) Double press the power key, then the left and right earphones will connect to each other.

WARRANTY

This CLOUD NINE i3 comes with a 12 month warranty. Should your product arrive and you notice it doesn't work or function correctly or is somehow broken, we will send you a replacement 100% FREE!

11

CLOUD NINE warranty does not cover physical damage from misuse or accidental damage to the product

Cloud Nine EU/UK
CLOUD NINE International Ltd,
Hornbeam Square West,
Harrogate, HG2 8PA

Cloud Nine Australia & New Zealand
CLOUD NINE ANZ Pty Ltd,
54 Balgowlah Road
Balgowlah,
New South Wales 2093,
Australia

CLOUD NINE EU
Authorised Representative
AR Service
77 Camden Street Lower
Dublin
D02 XE80
Ireland

CLOUD NINE® Product Support and Services

For more information on CLOUD NINE Product Support and Services, please visit www.cloudninehair.com

MADE IN CHINA



12