

Hanging Display Setup

(flip for diagram)

Lift wing nut (C) and washer (D) to expose holes in mounting piece (A).

Insert hook end of hangers (E) into the ten outer holes of mounting piece, alternating between short and long hangers. Spiral ends will create a two-tiered “tree” effect.

If a hangtag is provided, wrap hangtag string around threaded screw.

Drop washer and tighten wing nut. Position hangtag string to fall beneath hangers.

Hang display. The display holds 10 small Woodstock Chimes or Rainbow Makers.

